

PART NUMBER	DESCRIPTION	REF. NO.
2203	WASHER	1C07
2204	WASHER	1C09
2204	WASHER	1E07
2204	WASHER	1K04
2206	WASHER	1L03
2208	WASHER	1110
2251	WASHER	1J03
2550	WASHER	1C10
2550	WASHER & PLATE TO DAMPER	1C03
2851	WASHER	1K04
2920	WASHER	1C07
2920	WASHER	1K04
3036	LOCKWASHER	1C10
3074	WASHER	1E07
3074	WASHER	1102
3075	BOLT	1E07
3078	WASHER	1E07
3414	SPLIT PIN	1C06
3902	WASHER	1104
3911	WASHER	1C06
4047	WASHER	1104
4265	WASHER	1G05
4865	WASHER	1J03
4865	WASHER	1K04
12453	PARK SWITCH (WIPE MOTOR)	1L12
44620	SPRING	1G03
44630	D/C LOCKWASHER	1H04
50642	CLIP	1102
61917	GROMMET	2C04
61917	GROMMET	1L11
61917	GROMMET	2E02
6136	SCREW	1102
78494	SCREW	1105
78604	SCREW-PIPE TO MANIFOLD	1110
78662	SCREW	1C02
79127	CLIP	1L14
79142	SCREW	1M03
102801	WASHER	1F04
122445	CLAMP-TUBE TO UPPER COLUMN	1G02
125781	LOCATING SCREW	1G02
125782	LOCATING PLATE-TUBE TO UPPER COLUMN	1G02
130882	CLIP	1M05
134529	STOP LAMP SWITCH	1L16
138466	NUT WHEEL TO COLUMN	1G02
138514	WHEEL NUT SPANNER	2E02

2F02

PART NUMBER	DESCRIPTION	REF. NO.
142333	WASHER	1F04
142619	SLEEVE	1M05
144255	LOCKTITE	2E03
144262	LOCKTITE ADHESIVE	2E03
144268	LOCKTITE SEALANT	2E03
144432	HANDBRAKE WARNING SWITCH	1H06
144938	HOSE	1J05
144938	HOSE	1J07
145892	STRAP	1G05
146303	SHIM	1E06
146974	COTTER PIN	1F02
147990	ALTERNATOR FAN	1L04
149615	HOSE	1106
149878	LOCKTITE COMPOUND	2E03
150844	MOTOR FIXING PAD	1L12
150881	PEDAL RUBBER	1H03
150881	RUBBER PEDAL PAD	1H04
150930	PIPE CLIP	1111
150930	PIPE CLIP	1J05
150930	PIPE CLIP	1J07
150993	CLAMP PLATE	1H07
151210	HOSE-OIL COOLER PIPES	1E14
151244	CIRCUIT BREAKER HEADLAMP	1M06
151353	BOOT LAMP	1L11
152091	RUBBER-PEDAL PAD(AUTO)	1H04
152251	CABLE FORK END	1H07
152597	BOLT-LOCK TO COLUMN	1L14
152597	BOLT-LOCK TO COLUMN	1G02
153041	CLIP - CABLE TO PEDAL	1104
153109	CLIP	1L15
153109	CLIP	1L17
153317	P.B.C GREASE 4.5 OZ	2E03
153661	RETURN SPRING	1104
153675	JOINT PIN	1104
154036	EDGE FINISHER	1M05
154447	SHIM	1F05
154545	END PLUG-ROCKER SHAFT	1C06
154577	DELAY UNIT	1M06
154723	DRAIN TUBE	1K06
154865	UNION ADAPTOR	1E05
155455	LINKAGE CLIP	1E14
155568	BATTERY CARRIER	1M06
155645	T PIECE	1J04
155793	UPPER MOUNTING RUBBER	2C02
157387	HOSE	1102

2F02

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		

2F02

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
157387	HOSE	1K02	253225	BOLT	
158501	HARNESS DIODE	1M02	253407	BOLT	1L04
159003	PLATE	1003	253950	BOLT(3/8UNCX11/4")	1C02
159209	LOWER MOUNTING RUBBER	2C02	253955	BOLT(5/16"X5 1/2")	1L03
159212	SPACER	2C02	254021	BOLT	1C07
					1J03
159433	HOSE	1J05	254021	BOLT(5/16UNCX13/8")	
159433	HOSE	1J07	254024	BOLT(5/16UNCX13/4")	1L03
159798	SPECIAL WASHER	2C02	254031	BOLT(5/16UNCX13/4")	1C06
159814	HOSE	1J05	254041	BOLT	1L03
160021	LAMP HOLDER	1L15	254045	BOLT	1C09
					1C07
160021	LAMP HOLDER (FACIA PANEL)	1L14	254045	BOLT	
160108	LOCKNUT	1J06	254045	BOLT	1C09
160108	LOCKNUT-EGR VALVE	1J03	254048	BOLT	1E07
160222	CLIP (UNIT)	1L16	254810	NUT	1E07
160377	CLIP	1M05	254812	NUT	1J03
					1J03
213578	JOINT WASHER	1C02	254831	NUT	
213744	OIL SEAL	1C07	254831	NUT	1C02
219002	SPEEDO DRIVEN GEAR	1E13	254831	NUT PULLEY & PLATE TO DAMPER	1L03
219002	SPEEDO DRIVEN GEAR-21 TOOTH(GREEN)	1E05	255202	BOLT - BRACKET TO CYLINDER HEAD	1C03
219003	SPEEDO DRIVEN GEAR	1E05	255204	BOLT	1C02
					1J04
232043	WASHER	1J08	255205	BOLT	
232043	JOINT WASHER	1C08	255425	BOLT	1C07
236022	JOINT WASHER	1C08	255427	BOLT	1C02
243967	WASHER	1C08	255444	BOLT	1E07
243967	WASHER	1C04	255466	BOLT FLYWHEEL	1E07
					1E02
243996	WASHER	1C10	256025	BOLT(5/16UNFX17/8")	
252513	STUD	1C02	256200	BOLT	1L03
252514	STUD	1C09	256222	BOLT(5/16UNFX11/2")	1C07
252517	STUD	1C02	256223	BOLT PULLEY & PLATE TO DAMPER	1L03
253004	BOLT	1C08	257004	BOLT	1C03
					1L13
253004	BOLT	1E07	257005	BOLT	
253004	BOLT	1K04	257011	NUT	1C09
253007	BOLT	1J03	257017	BOLT	1E09
253007	BOLT	1K04	257020	BOLT	1C02
253010	BOLT	1C07	257020	BOLT	1C04
					1L12
253025	WASHER	1E07	257020	BOLT	
253027	BOLT(5/16UNFX7/8")	1C08	257064	BOLT	1L13
253045	BOLT	1E07	270005	SCREW	1C02
253048	BOLT(3/8UNCX11/8")	1J03	271013	O RING	1J04
253049	BOLT	1L03	271013	O RING	1E05
					1E05
253051	BOLT	1L02	271013	O RING	
253206	BOLT	1C07	271013	O RING	1E13
253206	BOLT	1J03	311346	SCISSOR JACK	1E13
253206	BOLT	1C02	313484	CLIP	2E02
253209	BOLT	1L03	367838	LOCKNUT	1J05
					1L15

2F03

2F03

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
367838	LOKUT NUT	2D02	532319	O RING	1C02
367838	LOKUT NUT	2D03	532943	PAD	1E04
367838	LOKUT NUT	1L14	533360	BALL BEARING	1E04
369699	WASHER	1K03	534790	NUT	1I05
500201	FILLER CAP (CLUTCH MASTER CYLINDER)	1D04	539707	PINION BEARING FRONT	1F04
502116	PLUG	1D02	541215	GROMMET	1I02
506542	CIRCLIP	1D03	542386	OLIVE	1I05
506542	CIRCLIP	1H04	550029	WAVED WASHER	1I04
508185	HARNESS CLIP	1M05	553252	BUTTON	2D15
508194	SCREW	2D13	553843	DOG PIN	1I04
510912	WASHER	1M03	553851	BEARING	1I04
510969	CLIP	1M05	554021	STUD	2D15
511191	WASHER	2C12	554407	RIVET	2D11
511384	SCREW	2D05	554517	SOCKET	2D15
511384	S/T SCREW-RETAINER TO BODY	2D08	558145	SPRING-THROTTLE RETURN	1I12
511541	SLEEVE	1M05	560772	RIVET	2D10
513123	FILLER CAP (BRAKE MASTER CYLINDER)	1M05	563767	RIVET	2D15
513604	BALL-VALVE BODIES	1E12	564258	O RING	1C06
513738	NUT MASTER CYLINDER ATTACHMENT	1M05	564832	SETScrew-RELEASE INNER CABLE TO LOCK	2C04
515060	ENTRY GROMMET (SIDE)	1L09	565443	COMBINATION TOOL	2E02
515061	ENTRY GROMMET (FLASH)	1L09	569313	RIVET	1L15
515218	UNIT RETAINING PLATE	1L08	569313	RIVET	1L17
516510	CLIP	1D04	573267	CABLE STRAP	1M05
517467	BUSH	1L07	575047	TUBE	1L11
517570	SCREW	1L11	575937	SCREW	2D05
517571	PLAIN WASHER-RETAINER TO	2D08	575956	RIVET	2D11
517689	PLUG (OIL PUMP COVER)	1C04	576185	PIPE CLIP	1E07
518540	FILLER CAP-STEERING PUMP	1E05	576469	DOOR LOCK ASSY	2C09
518564	SERVICE KIT-PUMP SEALS	1G06	576658	RIVET	2C06
518687	GASKET	1H02	576658	RIVET	2D05
518724	RETAINER PIA	1H02	577771	GROMMET	1M06
518760	CONTROL VALVE-PUMP	1G06	586655	BATTERY	1M06
518903	BOLT CABLES TO BATTERY	1M06	591208	BREATHER TUBE-GEARBOX	1E07
518904	NUT CABLES TO BATTERY	1M06	600396	GROMMET	1I05
519651	SCREW	1L14	600396	GROMMET	1L12
519651	SCREW	1L15	600399	BLANKING PLUG	2E02
520565	BOLT-CONVERTOR HOUSING ATTACHMENT	1E07	600569	JOINTING COMPOUND	2E03
520635	SEPERATING PLATE-VALVE BODY	1E12	601003	BOLT AND SPRING WASHER	1E10
520654	DRAIN PLUG-OIL PAN	1E08	601845	SCREW-CARB THROTTLE DISC	1I03
521453	CIRCLIP	1I12	601872	SCREW	1I03
521453	CIRCLIP	1I04	602061	NUT CAP TO CONNECTING ROD	1C04
522532	BUSH	1C09	602070	OIL SCREEN	1C02
522932	BUSH	1I12	602076	CLAMP	1C09
525105	SCREW-MOUNTING PLATE	1I10	602082	CONNECTING ROD ASSY	1C04
529364	PLUG	1D02	602097	BOLT BRACKET TO CYLINDER HEAD	1C06

2F04

2F04

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers-Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshe'll, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2F04

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
602098	WASHER	1C05	603378	PUSH ROD VALVES	1C06
602123	CORE PLUG	1C05	603428	SPRING PIN	1C09
602130	BOLT	1C02	603429	STUD	1I10
602141	DOWEL	1C02	603429	STUD	1C02
602142	SPRING	1C06	603431	NUT	1I05
602146	PLUG	1C02	603441	GASKET WATER OUTLET PIPE	1K04
602148	SPRING	1C06	603446	O RING	1L02
602152	BLANK	1C09	603554	VALVE GUIDE	1C05
602152	PLUG	1C02	603622	RETURN SPRING	1I04
602153	ROCKER RM	1C06	603659	DRAIN PLUG	1C02
602154	VALVE ROCKER ASSY LH	1C06	603664	BLANKING PLATE	1C08
602174	CORE PLUG	1C02	603672	PLUG LEAD RETAINER	1L03
602186	WASHER-ROCKER SHAFT	1C06	603672	RETAINER	1I02
602191	BOLT	1C05	603775	GASKET TIMING COVER	1C07
602192	BOLT	1C05	603943	REINFORCING STRIP SUMP	1C02
602193	BOLT	1C05	603944	BOLT-OIL SUMP TO BLOCK	1C02
602199	BOLT-OIL SUMP TO BLOCK	1C02	605410	ALTERNATOR FAN	1L05
602201	DOWEL	1C07	605410	ALTERNATOR FAN	1L04
602212	PLUG	1C02	605833	FLOAT	1I03
602227	BOLT	1C05	605843	SCREW SET	1I03
602236	BOLT INLET MANIFOLD CLAMP	1C09	605847	SCREW	1I03
602289	CUP PLUG	1C05	605848	DAMPER	1I03
602441	CIRCLIP	1E08	606168	FUEL FILTER	1I05
602444	CLAMP BRACKET	1C02	606168	SEATHER FILTER	1J04
602450	BOLT	1C05	606389	CLIP	2C11
602570	BOLT-ROCKER COVER ATTACHMENT	1C06	606389	TRIM CLIP	2D15
602561	O RING	1C02	606661	ROCKER SHAFT AND PLUGS ASSY	1C06
602567	HOSE CLIP	1J02	606747	SPRING	1M02
602587	REINFORCING PLATE	1C03	606792	SPRING	1I03
602609	BOLT CAP TO CONNECTING ROD	1C04	607181	PINION BEARING REAR	1F04
602610	WASHER	1C05	607448	GOVERNOR ASSY-AUTOMATIC GEARBOX	1E11
602648	JOINT PIN	1E08	608265	VACUUM UNIT	1L02
602905	BOLT - DRIVE PLATE	1D02	608817	TRIM CLIP	2D13
602906	WASHER - DRIVE PLATE	1D02	608862	TRIM CLIP	2D13
602910	BOLT (1/4UNF X 7/8)	1C04	609185	BLANKING PLUG	2E02
602912	BOLT (1/4UNC X 1 1/4)	1C04	610196	BUSH CRANKSHAFT	1C03
602913	BOLT (1/4UNC X 1 9/16)	1C04	610289	CHAINWHEEL CAMSHAFT	1C05
602915	DRAIN TAP	1C02	610327	JOINT WASHER	1I02
602953	ROLL PIN	1L02	610489	CLIP	1C02
603049	WATER OUTLET PIPE	1K04	610520	TRIM CLIP	2D13
603152	PLUG	1C02	610735	BOLT CRANKSHAFT	1D02
603224	PLUG	1C09	610736	WASHER CRANKSHAFT	1D02
603224	PLUG	1I08	610756	GASKET	1C07
603340	STARTER RING-DRIVE PLATE	1D02	610796	BATTERY PAD	1M06
603341	DRIVE PLATE	1D02	610988	CORE PLUG	1C02

2F05

2F05

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		

2F05

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
611089	PACKING	1C02	626733	LOKNUT	1L12
611323	STARTER KING-FLYWHEEL	1D02	627270	BLANKING PLUG	2E02
611409	OIL SEAL	1C02	627280	STUD-JACK POINT	2E02
611660	ROCKER AND SPRING SET	1C06	629287	NYLON WASHER-GRILLE TO FACIA	2D02
611733	SEAL	2C08	629288	ANCHOR BUSH-GRILLE TO FACIA	2D02
611795	BUSH	1108	629647	CLIP-SECURING HOULDING	2C15
611950	SCREEN	1108	630066	BLANKING PLUG	2E02
612219	TRUNNION-RELEASE INNER CABLE TO LOCK	2C04	632002	LAMP GASKET	1L11
612368	FLYWHEEL ASSY	1D02	632091	MIRROR DRUM	2C13
612473	TRUNK LID SUPPORT	2C12	634570	WASHER-LAMP ATTACHMENT	1L11
612475	SCREW	2C03	713501	SOCKET	2D11
612601	TEE PIECE - SCREENWASHER TUBES	1L12	713511	PLASTIC STUD	2D11
612898	PLUG	1C02	713531	RIVET	2D11
612989	CRANKSHAFT	1C03	715036	FRESH AIR PIPE	1K05
613377	WATER OUTLET PIPE	1K04	715389	RHEOSTAT SWITCH KNOB	1L15
613805	CLIP	1105	715390	CUT OUT SWITCH KNOB	1L15
613857	CLAMP	1L02	717105	SEAT HANDLE	2D11
614088	INLET VALVE	1C05	723290	RETAINING CLIP	2C12
614089	EXHAUST VALVE	1C05	800007	SCREW-BRAKE DRUM ATTACHING	1M02
614188	GEAR DISTRIBUTOR DRIVE	1C05	821450	TOOL BAG	2E02
614243	BUSH CRANKSHAFT	1C03	903076	WASHER	1C02
614293	ROD - OIL LEVER	1C02	90005032	CLIP	1J02
614555	OLIVE	1105	90254054	BOLT	1D03
614729	FAN	1C07	90254801	NUT	1C10
615889	SILL BUTTON	2C09	90568054	SEALING WASHER TRANSMITTER	1C05
618794	BUFFER-CURBY BOX LID	2D03	90601022	BEARING RING	1E10
619607	WASHER	2D07	90602025	KEY	1C03
621069	GROMMET	2E02	90602068	GASKET OIL SCREEN HOUSING	1C02
622247	LOCKING HANDLE LH	2D11	90602072	GASKET OIL PUMP COVER	1C04
622248	LOCKING HANDLE RH	2D11	90602202	DOMF	1C07
623312	PIPE CLIP	1M06	90602372	SPROCKET CRANKSHAFT	1C03
624155	PIPE CLIP	1J07	90603295	DISTANCE PIECE	1E02
624155	CLIP FUEL SYSTEM	1J05	90608280	RETAINING SCREW-CARB METERING NEEDLE	1J03
624569	BOLT	2D10	90611504	BOLT	1C09
624580	SHOULDERED BUSH	3D10	90611532	PIPE	1C09
624583	WASHER	2D10	90613659	PLATE	1C10
625038	CAP	1C06	22A 1613	NUT	1E06
625521	PIPE CLIP	1M06	2A 4067	GREASE CAP	1F02
625536	NUT	1E06	AA 604021	SCREW	2C05
625536	LOKNUT	1E14	AAP 25	CONTROL UNIT	1K05
625536	LOKNUT NUT	2D04	AAP 105	CONTROL LEVER LH	1K07
625536	LOKNUT-PLATE TO FACIA	1M06	AAP 106	CONTROL LEVER RH	1K07
626586	BONNET HINGE	2C03	AAP 128	WATER VALVE	1K07
626697	EYLET-RING	2D06	AAP 130	CONTROL VALVE	1K07
626698	EYLET-SAIL	2D06	AAP 156	EVAPORATOR AND SEAL	1K07

2F06

2F06

GROUP INDEX

Introduction	1B 2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L - M

Chassis, Subframes, Bodyshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2F06

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
AAP 187	EXPANSION VALVE	1K07	AAU 5508	SCREW	1L11
AAP 273	HEATER UNIT	1K05	AAU 6238	RIVET	1M07
AAP 274	AIR CONDITIONING UNIT	1K06	AAU 6238	RIVET	2D16
AAP 278	HARNES AND RESISTOR	1K07	AAU 6241	REAR BRAKE SPRING RH	1M02
AAP 291	WIRING HARNES-HEATER	1K05	AAU 6242	REAR BRAKE SPRING LH	1M02
AAU 1058	DRIVEN SHAFT ASSY-AUTOMATIC GEARBOX	1E11	AAU 6247	TENSION SPRING	1M02
AAU 1110	SEAT BELT WARNING BUZZER	1M06	AAU 6467	FLANGE-DRIVEN SHAFT	1E11
AAU 1332	OIL TUBE-FRONT SERVO RELEASE	1E12	AAU 6865	WIPER WHEEL LOCK	1L11
AAU 1506	SURGE PROTECTION DEVICE	1L04	AAU 6866	BUSH KIT	1L11
AAU 1525	INSULATOR	1I03	AAU 6889	CLIP	1L15
AAU 1828	THROTTLE SPINDLE(RH CARB)	1I03	AAU 6889	CLIP	1L17
AAU 1829	THROTTLE STOP LEVER	1I03	AAU 7085	STRAINER-FRONT PUMP	1E12
AAU 1876	BOOGLAMP SWITCH	1L16	AAU 7087	CONTROL UNIT INTERMITTANT	1L16
AAU 1909	TUBE ASSY	1L11	AAU 7176	CARTRIDGE REPAIR STRUT (SET OF TWO)	1F03
AAU 2021	RADIATOR AND SEALS (A/C UNIT)	1K07	AAU 7219	CARBURETTOR SERVICE KITS	1I03
AAU 2023	MOTOR-A/C UNIT	1K07	AAU 7220	CARB NEEDLE FED	1I03
AAU 2074	FORWARD SUN GEAR ASSY	1E11	AAU 7221	COMPENSATOR	1I03
AAU 2210	PULL OF SPRING	1M02	AAU 7222	CARBURETTOR SERVICE KITS	1I03
AAU 2212	HANDBRAKE LEVER RH	1M02	AAU 7268	CARB NEEDLE CALIF	1I03
AAU 2213	HANDBRAKE LEVER LH	1M02	AAU 7342	FILTER ELEMENT-AIR CLEANER	1I02
AAU 2252	CHARCOAL CANISTER	1J05	AAU 7374	CLIP	1J04
AAU 2304	OIL SEAL	1E13	AAU 7604	POPPET VALVE	1I03
AAU 2304	OIL SEAL	1E05	AAU 7631	BOLT	1E14
AAU 2871	RECTIFIER	1L04	AAU 7807	CLIP	1M05
AAU 2871	RECTIFIER	1L05	AAU 7924	SERVO KIT	1M04
AAU 2872	SURGE PROTECTION DEVICE	1L05	AAU 7925	BRAKE SERVO	1M04
AAU 2872	SURGE PROTECTION DEVICE	1L04	AAU 7960	FRONT BRAKE CALIPER RH	1M02
AAU 2873	TIMING ROTOR	1L02	AAU 7961	FRONT BRAKE CALIPER LH	1M02
AAU 3208	SUCTION TUBE	1E10	AAU 7962	BACKPLATE RH	1M02
AAU 3281	SCREW	2D10	AAU 7963	BACKPLATE LH	1M02
AAU 3583	ALTERNATOR REGULATOR	1L04	AAU 8016	PIPE CLIP	1I11
AAU 3584	ALTERNATOR COVER	1L04	AAU 8017	CARBON CANISTER	1J26
AAU 3585	SUPPRESSION CAPACITOR	1L04	AAU 8073	SERVICE KIT-PUMP SHAFT	1606
AAU 3615	BULBHOLDER	1L13	AAU 8074	SERVICE KIT-PUMP RESERVOIR	1606
AAU 3616	BULBHOLDER	1L13	AAU 8081	PISTON AND VALVE ASSY-FRONT CLUTCH	1E10
AAU 3688	NUT	2C14	AAU 8093	SCREW	2D10
AAU 3821	SWITCH	1M05	AAU 8111	SPIRE CLIP	1M08
AAU 3988	PICK UP MODLLE	1L02	AAU 8434	GASKET-GEARBOX OIL PAN	1E08
AAU 4015	SERVICE KIT-RING ROTOR AND	1G06	AAU 8796	NO AUTOMATIC GEARBOX ASSY	1E07
AAU 4072	WIPER MOTOR	1L11	AAU 8826	SCREW	2D11
AAU 4072	WIPER MOTOR	1L12	AAU 8994	BRAKE ADJUSTER KIT	1M03
AAU 4866	CLIP	1M05	AAU 9086	OIL PAN ASSEMBLY	1E05
AAU 4840	SOLENOID	1L07	AAU 9439	VALVE BODY ASSY	1E12
AAU 4952	STRAP	1L12	AAU 9435	SERVICE KIT-VALVE SPRINGS	1E13
AAU 5103	SCREW	2C07	AAU 4655	BRAKE DRUM	1M02

2F07

2F07

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Fiywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		

PART NUMBER	DESCRIPTION	REF. NO.
AB 108054	SCREW	2D12
AB 608051	SCREW	1K06
AB 606051	SCREW	1K08
AB 610051	SCREW	1M06
AB 610051	BOLT	1K02
AB 6100P1	SCREW	2D08
AB 612051	SCREW	1L12
AB 614101	SCREW	2D06
ACH 5103	FULCRUM BUSH	1M07
ACP 1121	SPRING-DOOR HINGE	2C05
AD 606074	SCREW	1M08
AD 608053	SCREW	2C09
AD 608053	SCREW	2D07
AD 608074	SCREW	2D02
AD 608084	BOLT	2D02
ADU 3298	BUTTON	2C15
AEU 1018	REPAIR KIT SLAVE CYL	1D04
AEU 1053	STOP PLATE-THROTTLE VALVE	1E12
AEU 1069	CAM ASSY-DOWNSHIFT VALVE	1E12
AEU 1070	DETENT LEVER	1E08
AEU 1071	DETENT SHAFT	1E08
AEU 1072	SPACER DETENT LEVER	1E08
AEU 1076	RETAINING PIN	1E08
AEU 1101	SWITCH-REVERSE AND INHIBITOR	1E08
AEU 1126	HEAT MASS COVER	1103
AEU 1127	THERMOSTAT HOUSING	1103
AEU 1136	CARB RETURN SPRING	1E13
AEU 1137	THROTTLE SPINDLE(LH CARB)	1103
AEU 1138	FAST IDLE LEVER	1103
AEU 1157	REAR HOUSING-AUTO GEARBOX	1E13
AEU 1173	SCREW	1103
AEU 1174	FLOATCHAMBER	1103
AEU 1194	MOUNTING PLATE-CLOCK	1L13
AEU 1196	MOUNTING-FLEXIBLE DRIVE	1L13
AEU 1238	PULLEY	1L05
AEU 1256	SERVICE KIT-THRUST WASHERS	1E13
AEU 1258	PISTON REAR SERVO	1E09
AEU 1259	PAWL-PARKING BRAKE	1E08
AEU 1260	ENTRE SUPPORT ASSY	1E11
AEU 1261	COVER-REAR SERVO	1E09
AEU 1264	GASKET-REAR HOUSING	1E13
AEU 1281	PULLEY	1L04
AEU 1281	PULLEY	1L05
AEU 1286	TORQUE CONVERTOR	1E07
AEU 1287	PLANET KIT	1E11

2F08

PART NUMBER	DESCRIPTION	REF. NO.
AEU 1288	PLANET COVER REAR DRUM	1E11
AEU 1353	HOUSING-TORQUE CONVERTER	1E07
AEU 1369	FLASH COVER P/I	1L02
AEU 1370	TIMING ROTOR P/I	1L02
AEU 1371	VACUUM UNIT P/I	1L02
AEU 1438	COVER-ALTERNATOR	1L05
AEU 1442	SCREW	1107
AEU 1473	HORN/DIP/FLASH SWITCH	1L16
AEU 1474	WIPER SWITCH	1L15
AEU 1482	ALTERNATOR REGULATOR	1L05
AEU 1515	SPEED DRIVING GEAR	1E11
AEU 1528	SURGE PROTECTION DEVICE	1L05
AEU 1532	SLIP RING AND BEARING KIT	1L05
AEU 1572	PICKUP MODULE P/I	1L02
AEU 1596	FRONT OIL PUMP ASSY	1E11
AEU 1607	WIPER MOTOR	1L11
AEU 1607	WIPER MOTOR	1L12
AEU 1608	RACK ASSEMBLY-WIPER MOTOR	1L12
AEU 1616	SUPPRESSION CAPACITOR	1L05
AEU 1629	SPEEDOMETER MPH	1L13
AEU 1630	SPEEDOMETER KPH	1L13
AEU 1631	SPEEDOMETER MPH	1L13
AEU 1632	FUEL GAUGE	1L13
AEU 1633	WATER TEMP GAUGE	1L13
AEU 1634	BATTERY INDICATOR	1L13
AEU 1635	CLOCK	1L13
AEU 1661	MASK-MOULDED INSTRUMENT	1L13
AEU 1663	SOLENOID	1L07
AEU 1664	BUSH	1L07
AEU 1670	RECTIFIER	1L05
AEU 1706	SCREW KIT	1L05
AEU 1708	SPACER KIT	1L05
AEU 1709	TERMINAL KIT (STUD)	1L05
AEU 1710	SUNDRY PARTS KIT	1L05
AEU 1726	BEARING KIT DRIVE END	1L05
AEU 1743	RECTIFIER	1L04
AEU 1743	RECTIFIER	1L05
AEU 1807	PUSH BUTTON-CLOCK	1L13
AEU 1808	PUSH BUTTON-SPEEDO	1L13
AEU 1809	BACK CASE INSTRUMENT PANEL	1L13
AEU 1810	INSTRUMENT UNIT LENS	1L13
AEU 1811	PRINTED CIRCUIT	1L13
AEU 1815	ALTERNATOR (NON DUCTED COVER)	1L05
AEU 1817	ALTERNATOR (DUCTED COVER)	1L05
AEU 1819	REGULATOR	1L05

2F08

GROUP INDEX

Introduction	1B-2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers, Wipers, Instruments	1L-M

Chassis, Subframes, Bodyshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2F08

PART NUMBER	DESCRIPTION	REF. NO.
AEU 1821	PULLEY	1L05
AEU 1822	COVER (NON DUCTED)	1L05
AEU 1823	COVER (DUCTED)	1L05
AEU 1826	WARNING LIGHT WINDOW ASSY	1L13
AFU 1006	PIN	1M06
AFU 1084	AIR PUMP ASSY	1J03
AFU 1085	CARBON CANISTER	1J06
AFU 1087	CLIP	1K02
AFU 1106	PIPE CLIP	1I11
AFU 1154	FIXNUT	1L15
AFU 1154	FIXNUT	1L17
AFU 1155	SCREW	1L15
AFU 1155	SCREW	1L17
AFU 1156	SCREW	1L15
AFU 1156	SCREW	1L17
AFU 1159	SCREW	2D02
AFU 1162	RIVET	1L15
AFU 1162	RIVET	1L17
AFU 1152	WASHER	1G02
AFU 1154	CLIP	1M03
AFU 1197	NUT-SELF LOCKING	2D10
AFU 1212	SCREW	1G04
AFU 1233	WELLNUT	1L12
AFU 1297	PIPE CLIP	1M05
AK 606061	SPIRE NUT	1K06
AK 606061	SPIRE NUT	1K08
AL 610021	FIXNUT	1K02
ARA 1501	LOCK RING	1I13
ARA 1501	SEALING RING	1I06
ARA 1502	GASKET	1I13
ARA 1502	SEALING RING	1I06
AS 602021	SCREW	2D10
AUD 3577	SEAL	1I08
AX 606021	SCREW	2C09
BAU 1711	FRONT OIL PUMP ASSY	1E10
BAU 1716	REPAIR KIT	1M05
BAX 1464	OUTER BALL JOINTS	1G04
BAX 2189	GAITER KIT	1G04
BAX 2190	VALVE SEAL REPAIR KIT	1G04
BBP 679	HANDLE ESCUTCHEON	2C09
BD 542	WASHER	1K02
BH 106051	BOLT	1E14
BH 106061	BOLT	2C12
BH 106121	BOLT	1I14
BH 108061	BOLT (M8X30MM)	1E05

2F09

PART NUMBER	DESCRIPTION	REF. NO.
BH 108071	BOLT (M8X35MM)	1E15
BH 108081	BOLT	1G02
BH 108081	BOLT (M8X40MM)	1E05
BH 108101	BOLT	1G02
BH 108101	BOLT	1I14
BH 108101	BOLT (M8X50MM)	1E05
BH 108111	BOLT (M8X55MM)	1E05
BH 108131	BOLT	1K03
BH 108141	BOLT	1I17
BH 108201	BOLT	1K03
BH 110111	BOLT	1F02
BH 110121	BOLT	1F05
BH 110121	BOLT	1G03
BH 110141	BOLT	1G03
BH 110151	BOLT	2C14
BH 110161	BOLT	1F02
BH 112081	BOLT	1K04
BH 112091	BOLT (M12X45MM)	1G03
BH 112101	BOLT	1F04
BH 112151	BOLT	1F02
BH 112181	BOLT	1E15
BH 112281	BOLT	2C02
BH 112401	BOLT	2C02
BH 504091	BOLT	1E12
BH 504111	BOLT	1E12
BH 504111	BOLT	1I08
BH 505241	BOLT (5/16" X 3")	1C07
BH 505321	BOLT	1I02
BH 505341	BOLT (5/16" X 4 1/2")	1C07
BH 505381	BOLT (5/16" X 4 3/4")	1C07
BH 505421	BOLT (5/16" X 5 1/4")	1C07
BH 505441	BOLT	1K04
BH 506121	BOLT	1C09
BH 506121	BOLT (3/8UNC X 1 1/2")	1G05
BH 506221	BOLT (3/8UNC X 2 3/4")	1G03
BH 604105	NUT	1C07
BH 604151	BOLT	1K04
BH 605131	BOLT	1K04
BH 606111	BOLT	1K04
BH 606321	BOLT	1K04
BHA 5067	DRIVE FASTENER	2D15
BHA 5067	DRIVE FASTENER	2D16
BHM 105219	TRANSFER KIT-BLACK	2C16
BHM 105220	TRANSFER KIT-ALUMINIUM	2C16
BHM 105221	TRANSFER KIT-BUCKSKIN	2C16

2F09

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers/Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2F09

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
BLS 101	BALL BEARING	1F04	CRC 1569	SPARK PLUG SPANNER	2E02
BMK 1900	GAITER TIE	1F03	CRC 2549	POUNTING RUBBER	1I11
BMK 2139	CABLE STRAP	1M05	CZA 7109	WINDOW REGULATOR HANDLE	2C08
BRC 1488	SCREW	2C09	CZA 7194	SCREW	2C08
C 38844 17	VACUUM PIPE	1I02	CZD 619	LOKUT NUT	2E05
C 38844 28	HOSE	1J06	CZD 1593	WASHER JET	1L12
C 38844 30	HOSE	1C0E	CZG 4707	DRIVE FASTENER	1I07
C 41220	INERTIA SWITCH	1L15	CZM 619	LOKUT NUT	1L10
C 41220	INERTIA SWITCH	1L17	CZH 619	LOKUT NUT	2C09
C 42171	NUT	1C08	CZH 884	TRIM STUD	2E05
C 43221	PUSH	1K03	CZK 3247	STRAP	1L12
C 43222	PROBE	1K03	CZK 3631	TRIM CLIP	2E06
C 43231	TAB WASHER	1I13	CZK 3754	SEATING WASHER	2C09
C 43595	HOSE CLIP	1I10	CZK 7056	CLIP	2C11
C 43965	BATTERY MANIFOLD	1M07	DAC 1211	POWER RESISTOR	1L16
C 44190	GASKET-DECEL VALVE	1I10	DAC 1671	INERTIA SWITCH	1L15
C 44700	LABEL (UNLEADED FUEL)	1L13	DAC 1671	INERTIA SWITCH	1L17
C 45085	SLEEVE-FUEL PIPE	1I05	DAC 2043	RESISTOR P/I	1L03
C 45757	WASHER	1C08	DAP 1695	AXLE BREATHER	1F04
C 45759	GASKET THERMOSTAT SWITCH	1C08	DAC 1721	THERMAL LIMITER	1L17
C 45759	COPPER WASHER	1K02	DRC 276	NUMBER PLATE LAMP	1L11
C 412191 1	BALANCE WEIGHT	1F06	DRC 1638	RESISTOR	1L02
C 412191 2	BALANCE WEIGHT	1F06	DRC 1721	THERMAL LIMITER	1L15
C 412191 4	BALANCE WEIGHT	1F06	DRC 1743	STARTER MOTOR	1L07
C 412191 5	BALANCE WEIGHT	1F06	DRC 1820	RELAY	1L15
C 412191 6	BALANCE WEIGHT	1F06	DRC 1820	RELAY	1L17
C 412199 3	BALANCE WEIGHT	1F06	DRC 2293	E.C.U	1M04
CAC 2263	FUEL PUMP	1I12	DRC 2338	SERVICE INTERVAL COUNTER	1L14
CAC 4269	FUEL PUMP	1I12	DRC 2567	ALTERNATOR	1L05
CAX 3469	INNER BALL JOINT	1G04	DRC 2640	STARTER MOTOR	1L07
CAX 2100	DAMPER TUBE ASSY RH	1F02	DRC 5017	CABLE CLIP	1M05
CAX 2101	DAMPER TUBE ASSY LH	1F02	DZA 925	ESCUTCHEON	2C08
CAX 2170	STEERING RACK	1G03	DZA 943	LINKAGE CLIP	2C08
CAX 2190	VALVE SEAL REPAIR KIT	1G04	DZA 1056	OUTER DISC LATCH-RH	2C09
CC 5014	HOSE CLIP	1J06	DZA 3450	DOOR HANDLE BRACKET	2C09
CC 5015	HOSE CLIP	1J06	DZB 431	UPPER HINGE ASSEMBLY	2C05
CCN 120	CIRCLIP	1E04	DZB 1057	OUTER DISC LATCH-LH	2C09
CD 31801 RB	NYLON MATERIAL	2D13	DZB 3159	MOTOR HEATER UNIT	1K05
CD 31802 PA	NYLON MATERIAL	2D13	DZB 3226	RADIATOR AND SEALS	1K05
CD 31804 AA	NYLON MATERIAL	2D13	DZB 3255	BUSH-HEATER PIPE TO MATRIX	1K05
CP 106081	P CLIP	1I11	DZB 4155	DOOR HINGE SHIM .60MM	2C05
CP 110191	P CLIP	1K02	DZB 4156	DOOR HINGE SHIM .775MM	2C05
CRC 250	GASKET-SERV. UNIT	1M04	DZB 4157	DOOR HINGE SHIM .975MM	2C05
CRC 307	LINK BUSH	1F02	DZB 5208	FIXING PLATE	2C13
CRC 1538	GASKET CLUTCH MASTER	1D04	EAC 1284	PRESSURE REGULATOR	1E08

2F10

2F10

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		

2F10

PART NUMBER	DESCRIPTION	REF. NO.
EAC 1383	COLD START INJECTOR	1110
EAC 1385	THERMO TIME SWITCH	1C08
EAC 1386	TEMPERATURE SENSOR	1C08
EAC 2272	HOSE CLIP	1J09
EAC 2272	CLIP WORM DRIVE	1J02
EAC 2414	SEALING RING-UPPER	1110
EAC 2415	SEALING RING-LOWER	1110
EAC 2512	HOSE CLIP	1107
EAC 3112	FUEL FILTER	1112
EAW 513	PLUNGER	1604
EAW 517	PIPE SEAT	1603
EAW 548	PIPE SEAT	1603
EAW 799	BUSH	1604
EAW 2951	LOCK WASHER	1604
EAW 3059	NEEDLE ROLLER BEARING	1604
EAW 4983	PIPE	1603
EAW 4985	PIPE	1603
EAW 4987	PIPE	1603
EAW 7336	VALVE ASSY	1604
EBW 1135	COVER-VALVE ASSY	1604
ERC 28	PEDESTAL	1C03
ERC 45	BOLT PULLEY & PLATE TO DAMPER	1C03
ERC 94	VISCOUS COUPLING	1C07
ERC 210	INSERT VALVE SEAT STD EXHAUST	1C05
ERC 211	INSERT VALVE SEAT STD EXHAUST	1C05
ERC 224	INSERT VALVE SEAT STD INLET	1C05
ERC 225	INSERT VALVE SEAT STD OS INLET	1C05
ERC 248	OIL FILLER NECK	1C06
ERC 255	CUP PLUG	1108
ERC 256	BLANK	1C09
ERC 303	BRACKET ALTERNATOR P/I	1103
ERC 304	DRIVE BELT	1J03
ERC 307	BRACKET ALTERNATOR	1103
ERC 386	PULLEY WATER PUMP & ALT	1C03
ERC 387	PULLEY WATER PUMP & ALT	1C03
ERC 389	PULLEY COMPRESSOR	1C03
ERC 400	DRIVE BELT	1K04
ERC 416	WASHER	1C03
ERC 417	BOLT	1C03
ERC 418	COVER ASSY TIMING CHAIN	1C07
ERC 421	VIBRATION DAMPER ASSY	1C03
ERC 446	VIBRATION DAMPER ASSY	1C03
ERC 466	CONTROL ROD	1J04
ERC 474	PULLEY	1C07
ERC 573	CAP-VALVE SPRINGS	1C05

2F11

PART NUMBER	DESCRIPTION	REF. NO.
ERC 577	OIL PUMP COVER ASSY	1C04
ERC 676	CYLINDER HEAD ASSY	1C05
ERC 882	V CONNECTOR	1J02
ERC 1043	HOSE	1J02
ERC 1069	SEPARATING BLADE	1C08
ERC 1102	INSULATOR	1102
ERC 1119	JOINT WASHER	1J03
ERC 1133	EXHAUST ADAPTOR	1J03
ERC 1168	PULLEY PAS PUMP	1C03
ERC 1185	POINTER	1C07
ERC 1188	STUD	1C07
ERC 1194	GASKET	1J03
ERC 1270	RELIEF VALVE	1J04
ERC 1309	VALVE SPRING	1C05
ERC 1351	OIL PUMP SHAFT AND GEAR ASSY	1C04
ERC 1353	GEAR DISTRIBUTOR	1102
ERC 1443	BRACKET	1104
ERC 1506	GAFFLE PLATE OIL SUMP	1C02
ERC 1508	PLUG	1C04
ERC 1512	SCREW	1C07
ERC 1519	WATER PUMP DRIVE	1C07
ERC 1540	WASHER VISCOUS COUPLING	1C07
ERC 1585	OIL SCREEN HOUSING ASSY	1C02
ERC 1587	STEADY BRACKET OIL SCREEN HOUSING	1C02
ERC 1628	DISTANCE PIECE	1C02
ERC 1629	THRUST WASHER	1C02
ERC 1637	COTTER-VALVES	1C05
ERC 1813	THRUST WASHER	1C02
ERC 1899	SLEEVE	1J02
ERC 1950	HEATSHIELD LH	1J02
ERC 1950	EXHAUST HEATSHIELD LH	1C10
ERC 1954	HEATSHIELD RH	1J02
ERC 1954	EXHAUST HEATSHIELD RH	1C10
ERC 2003	CAMSHAFT	1C05
ERC 2019	STUD	1C10
ERC 2065	AIR CLEANER LH	1102
ERC 2066	AIR CLEANER RH	1102
ERC 2068	JOINT WASHER	1102
ERC 2104	CARBURETTOR LH FED	1102
ERC 2104	CARBURETTOR ASSY LH FED	1103
ERC 2105	CARBURETTOR ASSY RH FED	1103
ERC 2105	CARBURETTOR PH FED	1102
ERC 2106	BRACKET	1105
ERC 2113	HOSE	1102
ERC 2124	ADAPTOR	1J02

2F11

GROUP INDEX

Introduction	1B 2B	Steering	1B
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1J - J
Cooling and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - 1N

Chassis, Subframes, Bodyshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2F11

PART NUMBER	DESCRIPTION	REF. NO.
ERC 2154	JOINT WASHER	1102
ERC 2235	HOSE AIR PUMP TO RH CHECK VALVE	1J04
ERC 2278	HOSE	1C09
ERC 2279	HOSE	1C07
ERC 2279	HOSE	1C09
ERC 2279	HOSE-WATER PUMP TO OUTLET PIPE	1K04
ERC 2312	PULLEY-STEERING PUMP	1605
ERC 2544	THROTTLE LINK ROD ASSY	1104
ERC 2632	COUNTERSHAFT-THROTTLE LINKAGE	1104
ERC 2672	INLET ADAPTOR	1J03
ERC 2690	TUBE	1C02
ERC 2692	IDLER PULLEY ASSY	1K04
ERC 2708	FRONT MOUNTING BRACKET	1605
ERC 2709	REAR MOUNTING BRACKET	1605
ERC 2741	LINER	1102
ERC 2763	DISTANCE PIECE	1605
ERC 2763	DISTANCE PIECE	1K04
ERC 2764	DISTANCE PIECE	1605
ERC 2772	CRANKCASE SUMP	1C02
ERC 2785	FUEL FEED PIPE ASSY	1105
ERC 2828	T PIECE RELIEF VALVE	1J04
ERC 2838	KEY CAMSHAFT	1C05
ERC 2839	SPACER	1C05
ERC 2901	EXHAUST MANIFOLD RH	1C10
ERC 2902	EXHAUST MANIFOLD LH	1C10
ERC 2930	BRACKET-FRONT	1K04
ERC 2931	BRACKET-REAR	1K04
ERC 2941	BRACKET RELIEF VALVE	1J04
ERC 2944	HOSE RELIEF VALVE TO LH CHECK VALVE	1J04
ERC 2973	BRACKET	1C02
ERC 2988	HOSE BREATHER	1J02
ERC 2989	OIL FILLER NECK	1C06
ERC 2990	ROCKER COVER ASSY RH	1C06
ERC 3004	BOLT	1K04
ERC 3010	COMPRESSOR	1K04
ERC 3024	HOSE MANIFOLD RESTRICTOR	1102
ERC 3028	HOSE	1102
ERC 3047	DISTRIBUTOR ASSY	1L02
ERC 3092	VACUUM PIPE RETARD	1102
ERC 3108	BALANCE TUBE	1102
ERC 3143	EGR VALVE	1J03
ERC 3161	PULLEY	1C07
ERC 3167	AIR PUMP PULLEY	1J03
ERC 3200	FILTER CAP	1C06
ERC 3201	FILTER CAP	1J04

2F12

PART NUMBER	DESCRIPTION	REF. NO.
ERC 3204	FILTER ELEMENT	
ERC 3209	FILTER	1C06
ERC 3214	ELBOW-BREATHER PIPE	1J04
ERC 3215	ADJUSTING LINK	1J03
ERC 3215	HOSE CLIP	1K04
ERC 3223	HOSE BREATHER	1107
ERC 3225	COMPRESSOR BRACKET ASSY	1J02
ERC 3232	AIR TEMPERATURE CONTROL UNIT	1K04
ERC 3322	BRACKET	1J02
ERC 3334	LINK ADJUSTER	1C04
ERC 3334	LINK ADJUSTER	1C03
ERC 3340	HOSE CANISTER TO T PIECE	
ERC 3346	CYLINDER HEAD ASSY	1J04
ERC 3365	SCREW-SLOWRUNNING	1C05
ERC 3377	MOUNTING PLATE-POTENTIOMETER	1110
ERC 3409	SETTING PLUG VALVE	1110
ERC 3409	SETTING PLUG VALVE	1J04
ERC 3432	CARBURETTOR ASSY-RH CALIF	
ERC 3432	CARBURETTOR ASSY RH	1103
ERC 3433	CARBURETTOR ASSY RH	1102
ERC 3433	CARBURETTOR ASSY LH CALIF	1102
ERC 3566	BRACKET-THROTTLE CONTROL	1103
ERC 3566	BRACKET-THROTTLE CONTROL	1113
ERC 3570	THROTTLE LEVER	
ERC 3571	STOP LEVER	1113
ERC 3573	SPRING PIN	1113
ERC 3574	SHAFT ASSY-THROTTLE COUPLING	1113
ERC 3579	NUC-THROTTLE SPINDLE	1113
ERC 3579	NUC-THROTTLE SPINDLE	1113
ERC 3580	FERRULE-SPRING LOCATING	
ERC 3588	AIR TUBE	1113
ERC 3617	EXTRA AIR VALVE	1J04
ERC 3619	POTENTIOMETER	1C09
ERC 3620	INJECTOR	1110
ERC 3620	INJECTOR	1110
ERC 3624	AIRFLOW METER	
ERC 3634	FERRULE BYPASS PIPE	1107
ERC 3671	DISC	1C09
ERC 3672	THROTTLE SPINDLE	1108
ERC 3734	FUEL RAIL-LH	1108
ERC 3734	FUEL RAIL-LH	1110
ERC 3735	FUEL RAIL-RH	
ERC 3742	HOSE-FUEL RAIL	1110
ERC 3773	MOUNTING PLATE-INJECTORS	1110
ERC 3774	CLAMP PLATE-INJECTORS	1110
ERC 3752	SPRING-THROTTLE RETURN	1110
ERC 3752	SPRING-THROTTLE RETURN	1113
ERC 3793	SPRING-THROTTLE RETURN	
ERC 3795	GASKET-COLD START INJECTOR	1113
ERC 3811	BRACKET PRESSURE REGULATOR	1110
ERC 3826	FLEX HOSE	1C06
ERC 3843	CUP PLUG	1J02
ERC 3843	CUP PLUG	1108

2F12

GROUP INDEX

Introduction	1B 2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flivwheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L - M

Chassis, Subframes, Bodyshe'll, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2F12

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
ERC 3849	HOSE-EXTRA AIR VALVE	1109	ERC 4879	BALANCE WEIGHT	1003
ERC 3851	P CLIP-TUBE TO PLENUM	1109	ERC 4880	BALANCE WEIGHT	1003
ERC 3857	HOSE-EXTRA AIR VALVE	1109	ERC 4949	HYDRAULIC TAPPET	1006
ERC 3858	TUBE	1109	ERC 4950	LEVER-THROTTLE SPRING	1112
ERC 3859	P CLIP-TUBE TO PLENUM	1109	ERC 4974	BRACKET-SOLENOID VALVE	1004
ERC 3861	HOSE RELIEF VALVE TO AIR PUMP	1004	ERC 4979	BREATHER HOSE	1004
ERC 3862	BRACKET ASSY	1112	ERC 4980	BREATHER HOSE	1004
ERC 3866	COUNTERSHAFT ASSY(AUTO)	1112	ERC 4991	SOLENOID VALVE	1004
ERC 3867	COUNTERSHAFT ASSY	1112	ERC 5085	BRACKET-IDLER SUPPORT	1004
ERC 3868	THROTTLE LINK ASSY	1112	ERC 5325	INLET MANIFOLD ASSY	1005
ERC 3870	THROTTLE LINK ASSY(AUTO)	1112	ERC 5427	WATER OUTLET ELBOW	1008
ERC 3932	ROCKER COVER ASSY LH	1006	ERC 5431	CONNECTOR ASSY	1009
ERC 3933	MOUNTING PLATE	1006	ERC 5434	WATER HOSE	1102
ERC 3957	BRACKET-THROTTLE CABLE	1112	ERC 5435	WATER HOSE	1102
ERC 3959	HOSE T PIECE TO RH CARB	1004	ERC 5436	TEE PIECE	1102
ERC 4020	EXHAUST MANIFOLD RH	1010	ERC 5490	ADJUSTED LINK-AIR PUMP	1003
ERC 4021	EXHAUST MANIFOLD LH	1010	ERC 5498	INLET MANIFOLD ASSY	1009
ERC 4056	ANCHOR BRACKET	1104	ERC 5614	BREATHER PIPE	1003
ERC 4097	SPRING LEVER	1104	ERC 5631	EGR VALVE	1006
ERC 4163	COUPLING SHAFT	1104	ERC 5636	PLUG	1010
ERC 4167	ROCKER COVER ASSY LH	1006	ERC 5637	HOSE CLIP	1006
ERC 4170	AIR INTAKE ADAPTOR	1102	ERC 5701	DECEL VALVE	1110
ERC 4176	HOSE CANISTER TO FILTER	1004	ERC 5928	HOSE-PLENUM TO	1109
ERC 4203	TUBE-AIR MANIFOLD	1004	ERC 6074	HOSE-SOLENOID VALVE	1109
ERC 4204	TUBE-AIR MANIFOLD	1004	ERC 6075	HOSE-SOLENOID VALVE TO	1109
ERC 4205	AIR MANIFOLD ASSY RH	1004	ERC 6141	DISTRIBUTOR ASSY P/I	1102
ERC 4206	AIR MANIFOLD ASSY LH	1004	ERC 6156	PIPE	1009
ERC 4211	SPHERICAL HOUSING	1113	ERC 6156	WATER OUTLET PIPE	1004
ERC 4212	HEATSHIELD	1113	ERC 6162	PLENUM CHAMFER	1108
ERC 4213	BRACKET-COUPLING SHAFT	1113	ERC 6193	LAMDA SENSOR	1113
ERC 4215	SPHERICAL BUSH	1113	ERC 6205	JACKET COVER	1109
ERC 4425	PLATE-PIPE TO JACKET COVER	1006	ERC 6208	GASKET	1109
ERC 4437	ASBESTOS COVER	1006	ERC 6272	FUEL FEED PIPE	1110
ERC 4466	HOSE-CONNECTOR TO PLENUM	1109	ERC 6311	HOSE MANIFOLD TO WATER	1108
ERC 4467	HOSE-CONNECTOR TO	1109	ERC 6311	HOSE MANIFOLD TO WATER	1003
ERC 4469	HOSE-CONNECTOR TO TUBE	1109	ERC 6312	HOSE WATER JACKET TO T PIECE	1108
ERC 4469	CONNECTOR	1109	ERC 6312	HOSE JACKET COVER TO T PIECE	1003
ERC 4491	SOLENOID VALVE	1109	ERC 6313	HOSE T PIECE TO HEATER PIPE	1003
ERC 4531	ADAPTOR	1006	ERC 6314	HOSE TANK ELBOW TO T PIECE	1003
ERC 4537	ADAPTOR-EGR VALVE OUTLET	1006	ERC 6315	TEE PIECE	1003
ERC 4714	STEADY BRACKET	1004	ERC 6427	VIBRATION DAMPER ASSY	1003
ERC 4735	STEADY BAR	1004	ERC 6436	ROD-OIL LEVEL	1002
ERC 4736	DISTANCE PIECE	1004	ERC 6437	TUBE	1002
ERC 4877	BALANCE LEIGHT	1003	ERC 6448	BREATHER HOSE	1004
ERC 4878	BALANCE WEIGHT	1003	ERC 6481	COMPRESSOR	1004

2F13

2F13

GROUP INDEX

Introduction
 Engine
 Flywheel and Clutch
 Gearbox and Propshaft
 Axles, Suspension, Drive Shafts, Wheels

1B 2B
 1C
 1D
 1E
 1F

Steering
 Brakes and Brake Controls
 Fuel, Exhaust and Emission Systems
 Cooling, Heating and Air Conditioning
 Electrical, Washers-Wipers, Instruments

1G
 1H
 1I-J
 1K
 1L-M

Chassis, Subframes, Bodyshe'll, Fittings
 Seats, Trim, Seats and Fixings
 Miscellaneous
 Numerical Index

2C
 2D
 2E
 2F

2F13

PART NUMBER	DESCRIPTION	REF. NO.
ERC 6521	VIBRATION DAMPER ASSY	1003
ERC 6552	WASHER	1005
ERC 6627	DISTANCE PIECE	1K04
ERC 6628	STEADY BRACKET	1K04
ERC 6874	BRACKET-REAR	1K04
ERC 6979	EGR PIPE ASSY	1J03
ERC 6982	PIPE-EGR VALVE TO PLENUM	1J06
ERC 7321	PLATE WASHER	1C10
ERC 7929	TIMING CHAIN	1C05
ERC 8114	POINTER	1C07
ERC 8407	IDLER PULLEY ASSY	1K04
34F 7526	ROKUT RIVET-FIXINGS MOUNTINGS	2C15
FAW 4101	NUT	1FG2
FF 2544	SPIRE NUT	2002
FF 4545	SPIRE NUT	1K06
FF 2545	SPIRE NUT	1K09
FF 4544	SPIRE CLIP	1K05
FF 4544	SPIRE NUT	1K06
FJ 2404	SPIRE CLIP	2007
FJ 2442	SPIRE CLIP	1L11
FJ 2444	SPIRE NUT	1M05
FJ 2444	SPIRE CLIP	2007
FJ 2444	FIX NUT	1L17
FJ 2485	LOKUT NUT	1M06
FRC 90	PROP SHAFT EOLT	1E15
FRC 93	RELEASE SLEEVE AND BEARING	1003
FRC 133	CLUTCH HOUSING	1003
FRC 142	COVER PLATE	1003
FRC 145	BOTTOM COVER-CONVERTOR HOUSING	1E07
FRC 3527	OIL PULVER TUBE-AUTO GEARBOX	1E07
FRC 3541	DIPSTICK-AUTO GEARBOX	1E07
FRC 5320	WASHER	1E03
FRC 5368	RELEASE SLEEVE AND BEARING	1003
FRC 5374	CLUTCH OPERATING LEVER	1003
FU 2544	NUT	2002
FU 2544	SPIRE CLIP	2015
FU 2544	SCREW	2016
FU 2544	SPIRE CLIP	1E14
FU 2545	SPIRE NUT	2004
FU 2545	SPIRE CLIP	2008
FU 2564	SPIRE CLIP	2007
FU 2564	SPIRE CLIP	2008
FU 2569	SPIRE NUT	1K06
FU 2578	SPIRE CLIP	2003
FU 2578	SPIRE NUT	2004

2F14

PART NUMBER	DESCRIPTION	REF. NO.
226 1486	BEARING	1E13
226 1486	BEARING-SPEEDO DRIVEN GEAR	1E05
226 1711	RETAINING PLATE	1E13
226 1711	RETAINER PLATE-SPEEDO CABLE	1E05
226 1928	PLUNGER	1E06
226 1949	PLUNGER SPRING	1E06
226 2202	FERRULE	1L14
246 6355	GASKET-SIDELAMP BASE	1L09
316 120	UPPER BEARING (FITTED IN TUBES)	1E02
86 8641	REPAIR KIT	1M03
26 8797	REPAIR KIT	1M03
26 8806	REPAIR KIT (CLUTCH MASTER CYL)	1E04
GAB 217	SERVICE KIT-OIL SEALS	1E13
GAB 304	PISTON RINGS KIT	1E13
GAB 408	GEARBOX GASKET KIT	1E13
GAB 506	FRONT CLUTCH PLATE KIT	1E10
GAB 610	REAR CLUTCH PLATE KIT	1E11
GAB 702	FRONT BRAKE BAND	1E09
GAB 709	REAR BRAKE BAND	1E09
CAC 100	LOCKTITE STD LOCK	2E03
GAC 147	P.B.C. GREASE 1 OZ	2E03
GAM 261	DOOR MIRROR LH	2C13
GAM 262	DOOR MIRROR RH	2C13
GAP 302	PAINT SPRAY-CARMINE	1E03
GAP 397	PAINT SPRAY-BROOKLAND GREEN	2E03
GAP 402	PAINT SPRAY-RUSSET BROWN	2E03
GAP 403	PAINT SPRAY-INCA YELLOW	2E03
GAP 415	AEROSOL PAINT LEYLAND WHITE	2E03
GAP 417	PAGEANT BLUE	2E03
GAP 418	VERMILLION	2E03
GAP 625	PENDELICAN	2E03
GAP 626	TURMERIC	2E03
GAP 627	MIDAS-METALLIC	2E03
GAP 629	PLATINUM-METALLIC	2E03
GAP 630	RICHELIEU	2E03
GAP 639	POSEIDON-METALLIC	2E03
GAP 640	PERSIAN AQUA-METALLIC	2E03
GAP 643	CARNELIAL	2E03
GAP 645	TRITON-METALLIC	2E03
GBF 301	BRAKE FLUID 2 OZ	2E03
GBF 202	BRAKE FLUID 16 OZ	2E03
GBF 203	BRAKE FLUID 32 OZ	2E03
GBH 219	BRAKE HOSE	1M06
GBH 414	FRONT BRAKE HOSE	1M05
GBP 245	DISC PAD KIT	1M03

2F14

GROUP INDEX

Introduction **1B-2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers/Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2F14

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
GBS 643	BRAKE SHOE	1M02	GHC 511	HOSE CLIP	1M02
GBS 797	BRAKE SHOE	1M02	GHC 1622	HOSE CLIP	1M04
GCC 275	CLUTCH COVER	1M02	GHF 132	BOLT/M6X40MM	1M04
GCI 114	COIL	1L03	GHF 133	BOLT	1M04
GCL 129	COIL P/I	1L03	GHF 133	BOLT	1M03
GCP 247	CLUTCH PLATE	1M02	GHF 133	SETSCREW-M6X25MM	1M04
GDC 117	DISTRIBUTOR CAP	1L02	GHF 133	BOLT	1M04
GEG 340	GASKET CYLINDER HEAD	1M05	GHF 133	BOLT	1M14
GEG 436	GASKET ROCKER COVER	1M05	GHF 133	BOLT	1M15
GEG 529	GASKET SUMP TO CYLINDER BLOCK	1M02	GHF 133	SETSCREW	1M04
GEG 645	SEAL	1M09	GHF 133	BOLT	1M04
GEG 655	GASKET INLET MANIFOLD	1M04	GHF 133	BOLT	1M07
GEG 697	PLATE	1C10	GHF 133	BOLT	1M06
GEG 697	GASKET INLET MANIFOLD	1M09	GHF 135	SETSCREW-M10X25MM	1M03
GEG 745	GASKET	1114	GHF 135	BOLT	1M07
GEG 1275	ENGINE GASKET SET	1C11	GHF 135	BOLT	1M07
GED 302	ALTERNATOR	1L04	GHF 200	NUT	1M17
GEX 1717	INTERMEDIATE EXHAUST PIPE ASSY RH-FEDERAL	1116	GHF 200	NUT	1110
GEX 1717	INTERMEDIATE EXHAUST PIPE ASSY LH-FEDERAL	1116	GHF 200	NUT	1113
GEX 1723	INTERMEDIATE EXHAUST PIPE	1116	GHF 200	NUT	1M12
GEX 1724	INTERMEDIATE EXHAUST PIPE	1116	GHF 201	NUT	1M02
GEX 1687	EXHAUST SILENCER RH	1117	GHF 201	NUT	1M04
GEX 1681	EXHAUST SILENCER LH	1117	GHF 201	NUT	1M07
GEX 1687	REAR SILENCER AND TAILPIPE RH	1117	GHF 201	NUT-5/16"	1M07
GEX 1687	REAR SILENCER AND TAILPIPE LH	1117	GHF 211	NUT	1L16
GEX 7337	LEIF	1117	GHF 211	NUT	1M07
GEX 7487	MOUNTING BULBER	1117	GHF 211	NUT	2C16
GEX 7497	EXHAUST SUMP STOP	1117	GHF 211	NUT	2M04
GFB 215	FAN BELT	1M07	GHF 212	NUT	1M06
GFB 215	FAN BELT	1L05	GHF 212	NUT	1111
GFB 20844	PUMP DRIVING BELT	1M05	GHF 212	NUT	1114
GFE 151	OIL FILTER	1M04	GHF 212	NUT	1M05
GFE 1093	AIR FILTER ELEMENT	1M07	GHF 212	NUT	1M05
GFU 107	FLASHER UNIT	1L15	GHF 212	NUT	1M05
GG 10P401	BOLT	1K02	GHF 212	NUT	1K05
GGB 504	BRUSH SET	1L04	GHF 212	NUT	1L09
GGR 504	BRUSH SET	1L05	GHF 212	NUT	1L14
GGB 513	BRUSH SET	1L0F	GHF 212	NUT	1M04
GHR 101	INNER BEARING-HUB TO STUD AXLE	1FL1	GHF 212	NUT	1M07
GHE 107	OUTER BEARING-HUB TO STUD AXLE	1F02	GHF 212	NUT	2C16
GHC 507	HOSE CLIP	1M06	GHF 213	NUT	1M14
GHC 709	HOSE CLIP	1M07	GHF 213	NUT	1M04
GHC 709	HOSE CLIP	1M09	GHF 213	NUT	1M05
GHC 709	HOSE CLIP	1M04	GHF 213	NUT	1112
GHC 709	HOSE CLIP	1K04	GHF 213	NUT	1117

2F15

2F15

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I - J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers-Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2F15

PART NUMBER	DESCRIPTION	REF. NO.
GHF 332	WASHER	1104
GHF 332	WASHER	1109
GHF 332	WASHER	1110
GHF 332	WASHER	1101
GHF 332	WASHER	1104
GHF 332	WASHER	1104
GHF 332	WASHER	1103
GHF 332	LOCKWASHER	1103
GHF 331	WASHER	1605
GHF 331	WASHER	1103
GHF 333	WASHER	1104
GHF 337	WASHER	1107
GHF 337	WASHER	1603
GHF 332	WASHER	1604
GHF 332	WASHER	1604
GHF 342	WASHER	1E05
GHF 342	WASHER	1E14
GHF 342	WASHER	1E14
GHF 342	WASHER	1E05
GHF 342	WASHER	1E04
GHF 342	WASHER	1E05
GHF 342	WASHER	1E06
GHF 342	WASHER	1107
GHF 342	WASHER	1112
GHF 342	WASHER	1114
GHF 342	WASHER	1116
GHF 342	WASHER	1117
GHF 342	WASHER	1K02
GHF 342	WASHER	1K02
GHF 342	WASHER	1K03
GHF 342	WASHER	1K03
GHF 342	WASHER	1L03
GHF 342	WASHER	1L09
GHF 342	WASHER	2004
GHF 342	WASHER	2005
GHF 342	WASHER	2009
GHF 342	WASHER	2C12
GHF 342	WASHER	2C14
GHF 342	WASHER	2C15
GHF 422	SCREW	1L10
GHF 423	SCREW	1K02
GHF 1002	SPIRE NUT	2010
GHF 1003	ROBUT RIVET	2C15
GHF 1231	TRIP CLIP	2002
GHF 1260	CABLE STRAP	1E05
GHK 1004	HUB BEARING AND SEAL KIT	1F02

2F17

PART NUMBER	DESCRIPTION	REF. NO.
GHK 102F	OIL SEAL SERVICE KIT	1F04
GHS 126	HUB OIL SEAL-MUD TO STUB AXLE	1F02
GHS 126	INNER OIL SEAL	1F04
GHS 187	OUTER OIL SEAL	1F04
GHT 170	PLUG LEAD KIT	1L03
GHT 182	PLUG LEAD KIT P/T	1L03
GL 10X254	BOLT	2010
GLB 207	BULB	1L10
GLB 239	BULB	1L11
GLB 256	BULB (12V 3W)	1L11
GLB 286	BULB	1L14
GLB 286	BULB	1E15
GLB 286	BULB	2004
GLB 286	BULB (12V 1.2W)	1L13
GLB 382	BULB-FLASH	1L09
GLB 504	BULB	1L13
GLB 504	BULB	1L10
GLB 443	BULB	1L15
GLB 989	BULB-SIDE	1L09
GLU 133	LIGHT UNIT	1L09
GLZ 610	FRONT SPOILER	2C16
GNC 223	BRAKE MASTER CYLINDER	1E05
GNS 117	OIL PRESSURE SWITCH	1004
GNS 123	OIL PRESSURE SWITCH	1004
GRA 117	ROTOR ARM	1L02
GRB 209	BEARING	1003
GRC 110	RADIATOR PRESSURE CAP	1K03
GRC 110	RADIATOR PRESSURE CAP	1K02
GRH 601	RADIATOR BOTTOM HOSE AC	1K02
GRH 603	RADIATOR BOTTOM HOSE	1K02
GRH 628	TOP HOSE	1K02
GRH 629	RADIATOR TOP HOSE A/C	1K02
GSA 374	REAR SHOCK ABSORBER	1F03
GSB 111	BRUSH SET	1L07
GSD 333	SPEEDOMETER CABLE	1L12
GSP 131	SPARK PLUG	1L03
GTG 125	GASKET OUTLET ELBOW	1005
GTR 110	THERMAL TRANSMITTER	1009
GT3 106	THERMOSTAT	1003
GTU 302	TOUCH IN PAINT-CARMINE	2E03
GTU 397	TOUCH IN PAINT-BROCKLANDS GREEN	2E03
GTU 402	TOUCH IN PAINT-RUSSET BROWN	2E03
GTU 403	TOUCH IN PAINT-INCA YELLOW	2E03
GTU 415	TOUCH UP PAINT LEYLAND WHITE	2E03
GTU 417	PAGEANT BLUE	2E03

2F17

GROUP INDEX

Introduction
 Engine
 Flywheel and Clutch
 Gearbox and Propshaft
 Axles, Suspension, Drive Shafts, Wheels

1B 2B
1C
1D
1E
1F

Steering
 Brakes and Brake Controls
 Fuel, Exhaust and Emission Systems
 Cooling, Heating and Air Conditioning
 Electrical, Washers-Wipers, Instruments

1G
1H
1I-J
1K
1L-M

Chassis, Subframes, Bodyshell, Fittings
 Fascia, Trim, Seats and Fixings
 Miscellaneous
 Numerical Index

2C
2D
2E
2F

2F17

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
GTU 418	VERMILLION	2E03	NH 2005	NUT	1123
GWB 200	WIPER BLADE	1L11	NH 2005	NUT	1J04
GWB 221	WIPER BLADE	1L11	NH 2005	NUT	2C09
SWC 1212	REAR WHEEL CYLINDER LH	1H02	NH 2011	NUT	1L16
GWP 204	WATER PUMP	1C02	HU 704	BOLT	2C01
GWW 125	SCREEN WASHER MOTOR	1L12	HU 706	BOLT	1E13
GWW 207	SCREEN WASHER TUBING	1L12	HU 959	BOLT	1K04
GWW 951	WASHER BOTTLE PLUG	1L12	JN 2108	NUT	1H07
7H 8850	BUSH	1E12	JN 2110	NUT	1E02
11H 1197	SEATING	1K02	JS 499	DIAPHRAGM	1103
13H 2023	CLIP	1E05	KRC 1002	BALANCE WEIGHT	1F06
13H 2494	LOCKWUT NUT	2B06	KRC 1002	BALANCE WEIGHT INNER	1F06
13H 2792	O RING	1E13	KRC 1004	BALANCE WEIGHT INNER	1F06
13H 2910	GROMMET	1102	KRC 1005	BALANCE WEIGHT INNER	1F06
13H 4949	BULBHOLDER	1L12	KRC 1005	BALANCE WEIGHT INNER	1F06
13H 6762	CIRCLIP	1E04	KRC 1047	BALANCE WEIGHT INNER	1F06
13H 8341	PIPE CLIP	1E16	KRC 1048	BALANCE WEIGHT INNER	1F06
13H 8690	BULBHOLDER	1L12	KRC 1049	BALANCE WEIGHT INNER	1F06
13H 8690	BULB HOLDER (FASCIA PANEL)	1L14	KRC 1050	BALANCE WEIGHT INNER	1F06
13H 8948	PLUG	1H05	KRC 1154	O RING	1K07
13H 9216	NON RETURN VALVE	1103	KRC 1156	O RING	1K03
13H 92	SERVO NON RETURN VALVE	1C02	KRC 1160	O RING	1K03
17H 7949	BRAKE SPRING CUP	1H02	ME 105041	NUT	1K04
17H 8032	REAR BRAKE SCOT	1H02	NH 105004	NUT	1L14
21H 5124	PLAIN NUT-HOLE TO STUB AXLE	1F02	NH 105041	NUT	1112
21H 5129	NUT RETAINER	1F02	NH 105041	NUT	1J05
21H 5253	COMPENSATOR LEVER	1H07	NH 105041	NUT	1J06
21H 5254	COMPENSATOR LEVER	1H07	NH 105041	NUT	1K03
27H 8426	BRAKE SHOE RETAINER	1H02	NH 105041	NUT	1L09
27H 8564	FRONT CLUTCH CYLINDER	1E10	NH 105041	NUT	1L10
37H 3694	FE-RULE	1L12	NH 105041	NUT	2C13
37H 4555	WASHER-OIL F/W DRAIN PLUG	1E02	NH 105041	NUT	2C14
37H 4702	BUSH	1E07	NH 105041	NUT	2C15
7H 8275	SERVO NON RETURN VALVE	1H04	NH 105041	NUT	2C15
37H 9863	VACUUM HOSE	1H04	NH 106001	NUT	1107
42H 1112	BALL	1E04	NH 108098	NUT	1114
42H 1113	BUSH	1E04	NH 504041	NUT	1E14
HB 710	BOLT	1E02	NH 504041	NUT	1117
HB 944	BOLT	1J03	NH 506071	NUT	1E05
HR 1022	BOLT	1F05	NH 504041	NUT	1K04
HB 1024	BOLT	1F05	NJ 105061	NUT	1115
HR 102111	BOLT	1H05	NJ 106061	NUT	1J06
NH 2005	NUT	1E02	NJ 106061	NUT	2C02
NH 2005	NUT	1104	NJ 108061	NUT	1E14
NH 2005	NUT	1112	NKC 362	RIVET	2C06

2F11

2F12

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission System	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		

2F18

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matieres illustree Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systemes d'alimentation en carburant, d'echappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aeration Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodyshell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axies, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2G01

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
NKC 365	RIVET	2D10	NY 108041	NUT	1M07
NKC 366	SCREW	2D02	NY 108041	NUT	1L09
NKC 373	RIVET	2D10	NY 110041	NUT	1C11
NKC 445	NUT	1L16	NY 110041	NUT	1E15
NKC 466	SCREW	1K08	NY 110041	NUT	1F02
NKC 468	SPIRE NUT	1K06	NY 110041	NUT	1F05
NKC 468	SPIRE CLIP	1K08	NY 110041	NUT	1G03
NKC 468	SPIRE CLIP	2D02	NY 110041	NUT	1M02
NKC 468	SPIRE CLIP	2D03	NY 110041	NUT	1I06
NKC 468	SPIRENUT - LENS COVER CONSOLE	1L13	NY 112041	NUT	1F02
NKC 474	RETAINING NUT	1G06	NY 112041	NUT	1F03
NKC 475	SCREW	2D03	NY 122041	NUT	2C02
NKC 477	DRIVE SCREW	2D03	PC 9	SPLIT PIN	1M04
NKC 478	SCREW	2D02	PC 9	SPLIT PIN	1M04
NKC 479	SCREW	2C15	PC 9	SPLIT PIN	1M07
NKC 480	WASHER	1K06	PC 9	SPLIT PIN	1I04
NKC 480	WASHER	1K08	PC 20	COTTER PIN	1F02
NKC 480	WASHER	2D02	PC 106241	CLEVIS PIN	2C12
NKC 480	PLAIN WASHER - CONSOLE TO BRACKET	1L13	PJ 8504	CLEVIS PIN	1I04
NKC 481	SPIRENUT	2D02	PJ 8805	CLEVIS PIN	1M07
NKC 482	WASHER	2C13	PJ 8806	CLEVIS PIN	1M06
NKC 482	WASHER	2D02	PJ 8809	CLEVIS PIN	1M04
NKC 482	PLAIN WASHER	2C15	PJ 8809	CLEVIS PIN	1M04
NKC 490	SPIRENUT	1K03	PKC 249	COWL AND BRACKET ASSY	1K03
NKC 508	SPIRE CLIP	1L11	PKC 307	AIR CLEANER ASSY	1I07
NKC 512	CIRCLIP	1L09	PKC 315	MAIN HARNESS	1M02
NKC 550	RIVET	2C08	PKC 379	FUEL PIPE	1I11
NKC 550	RIVET	2C12	PKC 381	FUEL PIPE-SPILL RETURN	1I11
NKC 578	ATTACHMENT BUTTON	2C16	PKC 383	PIPE	1J07
NK 2708	NUT	1M07	PKC 387	PIPE	1J07
NRC 2284	HOSE T PIECE TO LH CARB	1J04	PKC 390	FUEL PIPE	1I05
NT 108041	NUT	2C03	PKC 391	PIPE	1J05
NT 108041	NUT	1M04	PKC 392	FUEL PIPE	1J05
NT 108041	NUT	1E06	PKC 394	FUEL PIPE	1I11
NT 108041	NUT	1E14	PKC 449	UNDERSHIELD RH	1I15
NT 110041	NUT	2C03	PKC 450	UNDERSHIELD LH	1I15
NT 114040	NUT	1G04	PKC 624	MAIN HARNESS PI	1M02
NT 212041	NUT	1D04	PKC 625	FUEL INJECTION HARNESS	1M03
NT 606041	NUT	1I10	PKC 822	HEATSHIELD LH	1I15
NY 105041	NUT	1E15	PKC 823	HEATSHIELD RH	1I15
NY 106041	NUT	1M07	PKC 1245	FRONT EXHAUST PIPE ASSY LH	1I15
NY 106041	NUT	2C12	PKC 1246	FRONT EXHAUST PIPE ASSY RH	1I15
NY 108041	NUT	1F03	PKC 1287	HEADLAMP LIFT MOTOR	1L09
NY 108041	NUT	1F04	PKC 1295	STEERING WHEEL	1G02
NY 108041	NUT	1E02	PKC 1364	MAIN HARNESS	1M02

2602

2602

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers-Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2G02

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
PKC 1449	HEATSHIELD	1E14	RKC 3514	FUEL FILLER PIPE ASSEMBLY	1F06
PKC 1463	MAIN HARNESS	1M02	RKC 3523	FUEL TANK	1F06
PKC 1951	MAIN HARNESS PI	1M02	RKC 3536	BODY HARNESS	1F02
PKC 1952	MAIN HARNESS CAB	1M02	RKC 3556	FUEL TANK	1F06
PRC 1518	ALTERNATOR	1L04	RKC 3604	DOOR SPEAKER ASSY	1M08
RA 608236	RIVET	2D08	RKC 3607	FACIA HARNESS	1M03
RA 608236	RIVET	2D11	RKC 3616	RELAY PLATE	1M06
RA 608255	RIVET	2C15	RKC 3632	BODY HARNESS	1M02
RA 608255	RIVET	2D12	RKC 3723	CONTROL ROD-GEAR SELECTOR	1E14
RA 610373	RIVET	2D10	RKC 3854	AIR CON HARNESS	1M03
RA 612123	RIVET	1I15	RKC 3932	IGNITION HARNESS A/C	1M03
RKC 8	MOUNTING BRACKET	1H04	RKC 3979	WATERPROOF SHIELD	1L12
RKC 488	REAR ENGINE CROSSMEMBER	1E15	RKC 3984	STEERING COLUMN LOCK	1L16
RKC 532	RADIATOR MOUNTING CROSSMEMBER	1K02	RKC 4019	CHARCOAL CANISTER	1J05
RKC 552	STEERING UPPER COLUMN L H S	1G02	RKC 4133	SWITCH PANEL ASSY	1L14
RKC 927	CROSSMEMBER (SUSPENSION)	2C02	RKC 4134	SWITCH PANEL ASSY	1L15
RKC 971	STEERING PUFF	1G05	RKC 4168	CONSTANT PINJO. SHAFT	1E03
RKC 1001	BRAKE PIPE LHS	1H05	RKC 4225	RADIATOR ASSY A/C	1K02
RKC 1003	BRAKE PIPE LHS	1H05	RKC 4228	GEAR SELECTOR ASSY	1E14
RKC 1007	BRAKE PIPE LHS LH	1H05	RKC 4229	HOSE-OUTLET PIPE TO HEATER	1K04
RKC 1015	BRAKE PIPE CONNECTING WHEEL CYLINDERS	1H06	RKC 4238	REAR LOWER LINK ASSY	1F05
RKC 1016	BRAKE PIPE	1H05	RKC 4249	PLATFORM	1I07
RKC 1019	BRAKE PIPE	1H05	RKC 4341	HEATSHIELD	1I15
RKC 1027	BRAKE PIPE RH	1H05	RKC 4350	CARBON CANISTER	1J06
RKC 1033	REAR BRAKE PIPE	1H06	RKC 4353	BODY HARNESS PI	1M02
RKC 1036	BRAKE PIPE	1H06	RKC 4407	PARTIAL FLOW TANK	1K02
RKC 1038	BRAKE PIPE	1H05	RKC 4410	SUPPORT BRACKET	1I07
RKC 1818	REAR BRAKE DRUM	1M02	RKC 4448	IGNITION HARNESS A/C	1M03
RKC 2110	STEERING WHEEL	1G02	RKC 4481	AIR DAM	1K02
RKC 2111	ROAD WHEEL	1F06	RKC 4514	PROPELLOR SHAFT	1E15
RKC 2890	PROPELLOR SHAFT	1E15	RKC 4552	EXPANSION TANK	1K03
RKC 3092	CONDENSER	1K03	RKC 4552	PARTIAL FLOW TANK	1K02
RKC 3107	FAN MOTOR ASSY	1K03	RKC 4577	IGNITION HARNESS A/C	1M03
RKC 3112	RADIATOR MOUNTING CROSSMEMBER	1K02	RKC 4627	BODY HARNESS	1M02
RKC 3114	RADIATOR ASSY	1K02	RKC 4632	AXLE SHAFT RH	1F04
RKC 3270	UNDERSHIELD RH	1I16	RKC 4633	AXLE SHAFT LH	1F04
RKC 3271	UNDERSHIELD LH	1I16	RKC 4636	HOSE AIRFLOW METER	1I07
RKC 3274	EXHAUST DOWNPIPE ASSY RH	1I14	RKC 4669	SWITCH PANEL ASSY	1L14
RKC 3275	EXHAUST DOWNPIPE ASSY LH	1I14	RKC 4670	SWITCH PANEL ASSY	1L15
RKC 3288	OIL COOLER ASSY	1E14	RKC 4714	BRACKET-FUEL PUMP AND FILTER	1I12
RKC 3299	HEATSHIELD ASSY RH	1I16	RKC 4717	BRACKET	1I12
RKC 3300	HEATSHIELD ASSY LH	1I16	RKC 4821	HOSE-HEATER	1K04
RKC 3310	FRONT ANTI ROLL BAR	1F02	RKC 4830	RELAY PLATE	1M06
RKC 3336	REAR AXLE CASING	1F04	RKC 4884	HEATSHIELD LH	1I14
RKC 3513	FUEL FILLER PIPE ASSEMBLY	1F06	RKC 4885	HEATSHIELD RH	1I14

2603

2603

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L-M		

PART NUMBER	DESCRIPTION	REF. NO.
RKC 5098	5TH SPEED GEAR	1E04
RKC 5099	LAYSHAFT GEAR	1E05
RKC 5124	BODY HARNESS	1M02
RKC 5172	FUEL TANK	1I13
RKC 5259	LOW COOLANT CONTROL UNIT	1L15
RKC 5259	LOW COOLANT CONTROL UNIT	1L17
RKC 5415	LAYSHAFT GEAR	1E05
RKC 5518	DOOR SPEAKER ASSY	1M08
RTC 3	BOLT-CONVERTOR HOUSING	1E07
RTC 8	MOUNTING BRKT	1E03
RTC 8	RETURN SPRING-FRONT SERVO	1E09
RTC 9	"O" RING-DETENT SHAFT	1E08
RTC 10	COVER-FRONT SERVO	1E09
RTC 11	GASKET-FRONT SERVO COVER	1E09
RTC 12	BOLT	1E10
RTC 12	BOLT-SERVO COVERS ATTACHMENT	1E09
RTC 16	"O" RING	1E09
RTC 17	SPRING-SERVO	1E09
RTC 18	"O" RING-REAR SERVO COVER	1E09
RTC 19	GASKET-REAR SERVO COVER	1E09
RTC 22	ADJUSTING SCREW-REAR SERVO	1E09
RTC 23	ADJUSTING SCREW-FRONT SERVO	1E09
RTC 24	NUT-SERVO ADJUSTING SCREW	1E09
RTC 26	"O" RING-BREATHER ADAPTOR	1E07
RTC 27	LEVER-REAR SERVO	1E09
RTC 28	PIVOT PIN-SERVO LEVER	1E09
RTC 30	PIVOT PIN-BRAKE PAWL	1E08
RTC 31	TORSION SPRING-BRAKE PAWL	1E08
RTC 32	OPERATING LEVER	1E08
RTC 33	SPRING-OPERATING LEVER	1E08
RTC 34	PIVOT PIN-OPERATING LEVER	1E08
RTC 37	SCREW-INHIBITOR SWITCH	1E08
RTC 39	SEAL-OIL PUMP	1E10
RTC 40	"O" RING FRONT PUMP	1E10
RTC 42	SCREW AND LOCKWASHER	1E10
RTC 46	WAVED WASHER	1E10
RTC 48	OIL PRESSURE TUBE	1E10
RTC 49	OIL TUBE-CONVERTOR	1E10
RTC 50	SUPPLY TUBE-OIL COOLER	1E10
RTC 51	LOCATION PLATE-OIL TUBE	1E10
RTC 52	SCREW-LOCATION PLATE ATTACHMENT	1E10
RTC 57	HUB-FRONT CLUTCH	1E10
RTC 59	SNAP RING	1E10
RTC 59	SNAP RING	1E11
RTC 60	PISTON AND VALVE-REAR CLUTCH	1E11

2604

PART NUMBER	DESCRIPTION	REF. NO.
RTC 62	CLUTCH SPRING-AUTOMATIC GEARBOX	1E11
RTC 63	CLUTCH SPRING-AUTOMATIC GEARBOX	1E11
RTC 64	SNAP RING	1E11
RTC 71	RETAINER-CLUTCH	1E11
RTC 74	GEAR PING	1E11
RTC 75	SNAP RING	1E11
RTC 80	REAR SERVO STRUT	1E09
RTC 81	REAR SERVO STRUT	1E09
RTC 82	ROD-PARKING BRAKE	1E08
RTC 83	CAR PLATE	1E08
RTC 84	SCREW-CAM PLATE TO CASE	1E08
RTC 92	SCREW-END PLATE TO VALVE BODY	1E12
RTC 93	SCREW-END PLATE TO VALVE BODY	1E12
RTC 96	SCREW (24UNCX15/16")	1E12
RTC 97	SCREW(24UNCX13/8")	1E12
RTC 100	SCREW(32UNFX17/16")	1E12
RTC 101	SPACER-DETENT SPRING	1E12
RTC 102	DETENT SPRING AND ROLLER	1E12
RTC 108	OIL TUBE-FRONT SERVO RELEASE	1E12
RTC 110	LUBRICATION TUBE	1E08
RTC 111	OIL TUBE-REAR SERVO	1E12
RTC 112	OIL TUBE-REAR SERVO	1E12
RTC 113	OIL TUBE-REAR CLUTCH	1E12
RTC 114	GOVERNOR FEED TUBE	1E08
RTC 115	GOVERNOR PRESSURE TUBE	1E08
RTC 116	LUBRICATION TUBE	1E08
RTC 117	KICKDOWN CABLE	1E08
RTC 119	GASKET-KICKDOWN CABLE	1E08
RTC 121	BOLT-OIL PAN ATTACHMENT	1E08
RTC 124	GOVERNOR SPRING	1E11
RTC 131	SCREW-EXTENSION HOUSING	1E13
RTC 132	WASHER-EXTENSION HOUSING	1E13
RTC 135	WASHER-FLANGE ATTACHMENT	1E11
RTC 136	BOLT-FLANGE ATTACHMENT	1E11
RTC 150	STOP PLATE-THROTTLE VALVE	1E12
RTC 151	LOCKWASHER-GOVERNOR BOLT	1E11
RTC 152	BOLT-GOVERNOR	1E11
RTC 153	ONE WAY CLUTCH-AUTOMATIC GEARBOX	1E11
RTC 155	MAGNET-SERVO TUBE	1E12
RTC 178	INPUT SHAFT	1E10
RTC 185	SCREW-VALVE BODIES	1E12
RTC 189	SCREW-EXTENSION HOUSING	1E13
RTC 190	OIL RING	1E13
RTC 222	P CLIP A/C	1M05
RTC 246	PISTON SERVICE KIT	1E09

2604

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers-Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2G04

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
RTC 368	FRONT DRUM ASSY	1E11	RTC 2071	BOOK MIRROR SERVICE KIT	
RTC 447	OIL SEAL-REAR EXTENSION CASE	1E13	RTC 2104	ENGINE GASKET SET	2C13
RTC 454	PIPE PLUG	1E08	RTC 2117	BEARINGS CONNECTING ROD STD	1C11
RTC 458	PIPE-OIL COOLER	1E08	RTC 2117 1C	BEARINGS CONNECTING ROD .010" O/S	1C04
RTC 464	SCREW	1L08	RTC 2117 2C	BEARINGS CONNECTING ROD .020" O/S	1C04
RTC 537	SERVICE KIT-OUTER RACE AND CIRCLIP	1E11	RTC 2156 2C	PISTON AND RINGS ASSY-.020" O/S	1C04
RTC 609	WASHER	1C02	RTC 2156 5C	PISTON AND RINGS ASSY-STD	1C04
RTC 609	WASHER	1C07	RTC 2373	SHORT ENGINE ASSY	1C02
RTC 613	WASHER	1C02	RTC 2387	ROOF HANDLE ASSY	2D09
RTC 834	DRIVE KIT	1L07	RTC 2393	RACK SEALS REPAIR KIT	1E04
RTC 836	SEALING KIT	1L07	RTC 2394	VALVE SEALS REPAIR KIT	
RTC 1007	REGULATOR	1L04	RTC 2395	GAITER KIT	1E04
RTC 1004	RECTIFIER	1L04	RTC 2408	PISTON RINGS KIT(STD)	1C04
RTC 1008	GREASE	2E03	RTC 2408 2C	PISTON RINGS KIT(.020)	1C04
RTC 1115	BLEED NIPPLE	1D04	RTC 2524	DOOR HINGE LEAF ASSY	2C05
RTC 1166	FRONT BUMPER COVER KIT	2C14	RTC 2562	LAYSHAFT SERVICE KIT	1E05
RTC 1167	REAR BUMPER COVER KIT	2C15	RTC 2576	ENGINE GASKET SET	1C11
RTC 1156	GASKET-PUMP ADAPTOR	1E10	RTC 2591 K	GEAR BOX ASSY	1E02
RTC 1361	LENS RH	1L09	RTC 2591 R	GEAR BOX ASSY	1E02
RTC 1362	LENS LH	1L09	RTC 2670 N	GEARBOX ASSY	1E02
RTC 1363	LENS RH	1L10	RTC 2670 P	GEARBOX ASSY	1E02
RTC 1364	LENS LH	1L10	RTC 2683	GEARLEVER AND KNOB ASSY	1E06
RTC 1411	MINGE AND BRACKETS ASSY	1L09	RTC 7218	CLUTCH SLAVE CYLINDER	1D04
RTC 1466	BLEED SCREW	1H02	RU 608123	RIVET	2D11
RTC 1474	TRIMMER SCREW KIT	1L08	RU 608253	RIVET	2D12
RTC 1481	CARBURETTOR SERVICE KITS	1I03	SC 104141	SCREW	1I10
RTC 1528	BLEEDER SCREW (LH WHEEL)	1H02	SE 104121	SCREW	1K03
RTC 1704	OIL SEAL-GEARBOX CASE	1E08	SE 104141	SCREW	1L12
RTC 1718	BEARINGS STD	1C03	SE 104141	BOLT	1L16
RTC 1718 1C	BEARINGS-.010" O/S	1C03	SE 104201	SCREW	1L16
RTC 1718 2C	BEARINGS .020 O/S	1C03	SE 105121	BOLT	1I06
RTC 1817	CARBURETTOR SERVICE KITS	1I03	SE 105121	SCREW	1L14
RTC 1857	MOTOR GEAR ASSY	1L12	SE 105121	SCREW	2C02
RTC 1868	POP OUT UNIT	1L15	SE 105141	SCREW	1L0F
RTC 1883	BREATHER TUBE-GEARBOX	1E07	SE 105141	SCREW	2D10
RTC 1895	BALL JOINT KIT	1F02	SE 105161	SCREW	1I14
RTC 1896	TRANSMISSION OIL	2E03	SE 105251	SCREW	1I11
RTC 1925	RETURN SPRING	1I03	SE 105351	SCREW	1J06
RTC 1929	HEAT MASS ASSY	1I03	SE 106121	SCREW	1I10
RTC 1992	HEADLAMP MECHANISM LINK	1L09	SE 106121	SCREW	1I11
RTC 2044	OIL PRESSURE RELIEF VALVE SERVICE KIT	1C04	SE 106161	BOLT	1I07
RTC 2057	DRIVE SHAFT AND OIL PUMP GEARS KIT	1E05	SE 106201	BOLT	2C10
RTC 2058	SELECTOR FORK ASSY (5TH GEAR)	1E04	SE 106201	BOLT	2C12
RTC 2061	DIFF CASE AND GEARS KIT	1F04	SF 105123	SCREW	2D11
RTC 2063	WINDSCREEN GLAZING KIT	2C13	SF 105141	SCREW	1E14

2605

2605

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L-M		

2605

PART NUMBER	DESCRIPTION	REF. NO.
SF 106201	SCREW	2C09
SF 106301	SCREW	2C09
SG 104161	SCREW	2C13
SG 105144	SCREW	2C13
SH 104141	BOLT	1104
SH 105031	BOLT	1112
SH 105121	BOLT	1115
SH 105121	BOLT	2C08
SH 105141	BOLT	1L16
SH 105141	SCREW	1M05
SH 105151	SETScrew (M5x15MM)	1E06
SH 105251	BOLT	1J05
SH 106041	BOLT	1M06
SH 106101	BOLT	1J05
SH 106121	BOLT	1109
SH 106121	BOLT	1114
SH 106121	BOLT	2C08
SH 106121	SETScrew-M6x12MM	1E06
SH 106141	BOLT	1F02
SH 106141	BOLT	1G06
SH 106141	BOLT	1106
SH 106141	BOLT	1113
SH 106141	BOLT	1J05
SH 106141	BOLT	1J06
SH 106141	BOLT	1K05
SH 106141	BOLT	1K06
SH 106141	BOLT	1K08
SH 106141	BOLT	2D02
SH 106141	BOLT	1E04
SH 106141	BOLT	1G05
SH 106161	BOLT	1104
SH 106161	BOLT	1107
SH 106161	BOLT	1J05
SH 106161	BOLT	1M07
SH 106161	BOLT	2C03
SH 106161	BOLT	2C05
SH 106161	BOLT	2C12
SH 106161	BOLT	1K02
SH 106161	SETScrew-M6x16MM	1G03
SH 106201	BOLT	1E05
SH 106201	BOLT	1M07
SH 106201	BOLT	1107
SH 106201	BOLT	1L15
SH 106201	BOLT	1L17
SH 106201	BOLT	2C14

2606

PART NUMBER	DESCRIPTION	REF. NO.
SH 106201	BOLT	2C15
SH 106201	BOLT	2C16
SH 106201	SETScrew-M6x20MM	1E06
SH 106251	BOLT	2C14
SH 106251	BOLT	2C16
SH 106301	BOLT	1104
SH 106301	BOLT	1115
SH 106301	BOLT	2C03
SH 106351	BOLT	1114
SH 108161	BOLT	1116
SH 108161	BOLT	1117
SH 108161	BOLT	1K03
SH 108161	BOLT	2C08
SH 108161	BOLT	2C12
SH 108161	BOLT	1K02
SH 108161	SETScrew-M5x16MM	1F04
SH 108201	BOLT	1D03
SH 108201	BOLT	1E05
SH 108201	BOLT	1M04
SH 108201	BOLT	1M06
SH 108201	BOLT	1I07
SH 108201	BOLT	1112
SH 108201	BOLT	1116
SH 108201	BOLT	1117
SH 108201	BOLT	1L03
SH 108201	SETScrew-M8x20MM	1E14
SH 108301	BOLT	1E04
SH 110201	BOLT	1F04
SH 110251	BOLT	1M02
SH 110301	BOLT	1C11
SH 112301	SETScrew-M12x30MM	1D03
SH 504041	BOLT	1110
SH 504041	BOLT	1J06
SH 504045	BOLT	1102
SH 504051	BOLT	1113
SH 504061	BOLT	1110
SH 504151	BOLT	1C08
SH 504161	BOLT	1C08
SH 505051	BOLT	1G03
SH 505051	BOLT	1112
SH 505055	BOLT	1J04
SH 505061	BOLT	1C11
SH 505061	BOLT	1110
SH 505071	BOLT	1C08
SH 505081	BOLT	1102

2606

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Control **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers, Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**



PART NUMBER	DESCRIPTION	REF. NO.
SH 505081	SETSCREW (5/16UNCX1")	1605
SH 505101	SETSCREW-5/16"X11/4"	1607
SH 505141	BOLT	1603
SH 506071	BOLT	1605
SH 506095	SETSCREW-3/8"X11/8"	1610
SH 506121	BOLT	1605
SH 506161	BOLT	1609
SH 507081	BOLT	1611
SH 604051	BOLT	1113
SH 607121	BOLT	1604
SK 104060	SCREW	2009
SL 105121	SCREW	1108
SL 105161	SCREW	2010
SM 105161	SCREW	2013
SN 105105	BOLT	1116
SP 105251	BOLT	1603
SS 106251	SCREW	2012
SS 108351	SCREW	2012
SS 504121	SCREW SOCKET HEAD	1107
ST 106047	BOLT	2072
TE 108201	BOLT	2004
TE 108056	STUD	1610
TE 504081	STUD	1609
TE 504131	STUD	1609
TE 605101	STUD	1604
TE 605105	STUD	1610
TKC 63	LAYSHAFT GEAR (5TH SPEED)	1605
TKC 131	STRAP-FUEL TANK	1113
TKC 131	FUEL TANK STRAP	1106
TKC 235	STOP TAIL LAMP ASSY LH	1110
TKC 236	STOP TAIL LAMP ASSY RH	1110
TKC 253	REAR ANTI-ROLL BAR	1605
TKC 267	2ND SPEED GEAR	1604
TKC 268	MAINSHAFT 2RD SPEED GEAR	1603
TKC 240	INTERLOCK SPOOL	1604
TKC 302	OIL SEAL HOUSING	1604
TKC 735	1ST SPEED GEAR	1604
TKC 878	LOWER LINK ASSEMBLY RH	1602
TKC 879	LOWER LINK ASSEMBLY LH	1602
TKC 1024	GASKET (HYPOID HOUSING COVER)	1604
TKC 1095	OUTER TUBE LHS	1602
TKC 1195	5TH SPEED GEAR	1604
TKC 1205	TOP MOUNTING RUBBER	1603
TKC 1229	GASKET-CENTRE PLATE TO GEARCASE	1602
TKC 1236	GASKET-CENTRE PLATE TO EXTENSION CASE	1602

2607

PART NUMBER	DESCRIPTION	REF. NO.
TKC 1258	BRAKE PEDAL (AUTO)	1604
TKC 1266	BODY-GEARBOX OIL PUMP	1605
TKC 1274	SPEEDO DRIVEN GEAR	1604
TKC 1303	PIN (REVERSE LEVER MOUNTING)	1602
TKC 1320	EXTENSION CASE AND PUMP ASSY	1605
TKC 1329	FRONT ROAD SPRING	1603
TKC 1413	INTERLOCK SPOOL (5TH GEAR)	1604
TKC 1428	REVERSE OPERATING LEVER	1605
TKC 1477	1ST SPEED BUSH (3.236/40MM)	1604
TKC 1478	1ST SPEED BUSH (40.01/40.05MM)	1604
TKC 1479	1ST SPEED BUSH (40.06/40.10MM)	1604
TKC 1480	1ST SPEED BUSH (40.11/40.15MM)	1604
TKC 1481	1ST SPEED BUSH (40.16/40.20MM)	1604
TKC 1484	MOUNTING BRACKET	1603
TKC 1562	BAULK RING	1603
TKC 1562	BAULK RING	1604
TKC 1577	GEAR LAYSHAFT CLUSTER	1605
TKC 1605	RECEIVER DRYER	1603
TKC 1633	SELECTOR FORK	1604
TKC 1634	SELECTOR FORK (3RD/4TH GEAR)	1604
TKC 1676	MAINSHAFT FLANGE	1604
TKC 1885	COVER (HYPOID HOUSING)	1604
TKC 2056	COVER PLATE (GEARCHANGE EXTENSION)	1606
TKC 2209	GEAR SELECTION SHAFT	1604
TKC 2404	REAR ROAD SPRING	1605
TKC 2413	FUEL PIPE SLEEVE	1106
TKC 2460	HORN-HIGH NOTE	1115
TKC 2460	HORN-HIGH NOTE	1117
TKC 2461	HORN-LOW NOTE	1115
TKC 2461	HORN-LOW NOTE	1117
TKC 2587	TACHOMETER	1113
TKC 2642	REAR ENGINE MOUNTING RUBBER	1615
TKC 2664	SELECTOR SHAFT (1ST/2ND GEAR)	1604
TKC 2735	HANDBRAKE CABLE	1607
TKC 2945	CROWN WHEEL AND PINTON ASSY	1604
TKC 2980	FLEX NOSE	1602
TKC 3084	DISC SHIELD RH	1602
TKC 3085	DISC SHIELD LH	1602
TKC 3086	FRONT ROAD SPRING	1603
TKC 3111	MAINSHAFT ASSEMBLY	1603
TKC 3157	BRAKE DISC FRONT LH RH	1602
TKC 3343	FUSEBOX MOUNTING PLATE	1606
TKC 3361	CLUTCH PEDAL	1603
TKC 3381	BAULK RING	1604
TKC 3390	IGNITION SWITCH	1116

2607

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers/Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2607

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
TKC 3410	FUEL PUMP	1106	TKC 3964	FOGLAMP SWITCH	1L14
TKC 3413	UNDERSHIELD FRONT RH-FEDERAL	1116	TKC 3964	FOGLAMP SWITCH	1L15
TKC 3414	UNDERSHIELD FRONT LH-FEDERAL	1116	TKC 3965	HEATED BACKLIGHT SWITCH	1L14
TKC 3415	FUEL TANK UNIT	1113	TKC 4000	HOSE-AIR CLEANER TO	1107
TKC 3415	PETROL TANK GAUGE UNIT	1104	TKC 4010	MAIN GEAR SELECTOR SHAFT	1E04
TKC 3429	OIL PIPE FRONT(FEED)	1E14	TKC 4017	DELAY UNIT	1E16
TKC 3430	OIL PIPE REAR(RETURN)	1E14	TKC 4123	PIPE	1E05
TKC 3431	OIL PIPE HOSE TO COOLER	1E14	TKC 4125	PIPE	1E05
TKC 3432	OIL PIPE HOSE TO COOLER(FEED)	1E14	TKC 4160	WATER SHIELD	1L03
TKC 3457	THERMAL BLANKET	1114	TKC 4247	GRASS SHIELD	1115
TKC 3492	PIPE	1K06	TKC 4299	GEAR LEVER ASSY	1E06
TKC 3493	HOSE	1K03	TKC 4413	BRACKET-POWER RESISTOR	1L16
TKC 3494	HOSE	1K03	TKC 4505	CLUTCH PEDAL	1E03
TKC 3495	HOSE - A/C	1K06	TKC 4527	EMISSION HOSE	1J05
TKC 3533	CONSTANT PINION SHAFT	1E03	TKC 4558	IGNITION HARNESS	1M03
TKC 3554	REAR AXLE ASSEMBLY	1E03	TKC 4559	REVERSE BULK PLATE	1E06
TKC 3591	EXHAUST DOWNPIPE ASSY RH	1114	TKC 4564	EMISSION HOSE	1J05
TKC 3592	EXHAUST DOWNPIPE ASSY LH	1114	TKC 4633	WASHER-LAYSHAFT (1.69MM)	1E05
TKC 3624	BRAKE PEDAL	1M04	TKC 4635	WASHER-LAYSHAFT (1.75MM)	1E05
TKC 3655	PIPE	1E05	TKC 4637	WASHER-LAYSHAFT (1.51MM)	1E05
TKC 3667	PRESSURE REDUCING VALVE	1M05	TKC 4639	WASHER-LAYSHAFT (1.57MM)	1E05
TKC 3728	FUEL FILLER HOSE	1106	TKC 4641	WASHER-LAYSHAFT (1.93MM)	1E05
TKC 3729	OIL PIPE-FRONT FEED	1E14	TKC 4643	WASHER-LAYSHAFT (1.99MM)	1E05
TKC 3730	OIL PIPE-REAR RETURN	1E14	TKC 4645	WASHER-LAYSHAFT (2.05MM)	1E05
TKC 3731	OIL PIPE- HOSE TO COOLER(FEED)	1E14	TKC 4647	WASHER-LAYSHAFT (2.11MM)	1E05
TKC 3732	OIL PIPE-HOSE TO COOLER(RETURN)	1E14	TKC 4649	WASHER-LAYSHAFT (2.17MM)	1E05
TKC 3738	HEADLAMP ASSY	1L08	TKC 4651	WASHER-LAYSHAFT (2.23MM)	1E05
TKC 3741	FRONT SIDELAMP RH	1L09	TKC 4653	WASHER-LAYSHAFT (2.29MM)	1E05
TKC 3742	FRONT SIDELAMP LH	1L09	TKC 4655	WASHER-LAYSHAFT (2.35MM)	1E05
TKC 3770	BRACKET	1E04	TKC 4657	WASHER-LAYSHAFT (2.41MM)	1E05
TKC 3776	TIE ROD LEVER RH	1E02	TKC 4659	WASHER-LAYSHAFT (2.47MM)	1E05
TKC 3777	TIE ROD LEVER LH	1E02	TKC 4661	WASHER-LAYSHAFT (2.53MM)	1E05
TKC 3831	DOOR HARNESS	1M03	TKC 4663	WASHER-LAYSHAFT (2.59MM)	1E05
TKC 3842	PRESSURE CUT IN SWITCH	1L15	TKC 4843	SELECTIVE WASHER (1.57MM)	1E03
TKC 3842	PRESSURE CUT IN SWITCH	1L17	TKC 4845	SELECTIVE WASHER (1.63MM)	1E03
TKC 3858	SWITCH PANEL ASSY	1L14	TKC 4847	SELECTIVE WASHER (1.69MM)	1E03
TKC 3860	SWITCH PANEL ASSY	1L15	TKC 4849	SELECTIVE WASHER (1.75MM)	1E03
TKC 3873	MOUNTING BRACKET	1J05	TKC 4851	SELECTIVE WASHER (1.81MM)	1E03
TKC 3936	RHEOSTAT SWITCH	1L15	TKC 4853	SELECTIVE WASHER (1.87MM)	1E03
TKC 3951	INTERIOR LAMP	1L11	TKC 4855	SELECTIVE WASHER (1.93MM)	1E03
TKC 3954	LOWER BRACKET	1107	TKC 4857	SELECTIVE WASHER (1.99MM)	1E03
TKC 3962	HAZARD SWITCH	1L15	TKC 4859	SELECTIVE WASHER (2.05MM)	1E03
TKC 3962	HAZARD SWITCH	1L14	TKC 4861	SELECTIVE WASHER (2.11MM)	1E03
TKC 3963	LIGHT SWITCH	1L15	TKC 4863	SELECTIVE WASHER (2.17MM)	1E03
TKC 3963	LIGHT SWITCH	1L14	TKC 4865	SELECTIVE WASHER (2.23MM)	1E03

2608

2608

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L-M		

2608

PART NUMBER	DESCRIPTION	REF.NO.
TKC 4867	SELECTIVE WASHER(2.29MM)	1E03
TKC 4869	SELECTIVE WASHER(2.35)	1E03
TKC 4871	SELECTIVE WASHER(2.41)	1E03
TKC 4873	SELECTIVE WASHER(2.47)	1E03
TKC 4875	SELECTIVE WASHER(2.53)	1E03
TKC 4877	SELECTIVE WASHER(2.59)	1E03
TKC 4879	SELECTIVE WASHER(2.65)	1E03
TKC 4881	SELECTIVE WASHER(2.71)	1E03
TKC 4883	SELECTIVE WASHER(2.77)	1E03
TKC 5050	THERMOSTAT SWITCH	1C08
TKC 5051	INTERIOR LAMP	1L11
TKC 5053	FOGLAMP SWITCH	1L14
TKC 5053	FOGLAMP SWITCH	1L15
TKC 5054	HEATED BACKLIGHT SWITCH	1L14
TKC 5083	COMBINED RELAY	1M04
TKC 5087	HEATED BACKLIGHT SWITCH	1L14
TKC 5088	HAZARD SWITCH	1L14
TKC 5088	HAZARD SWITCH	1L15
TKC 5089	LIGHT SWITCH	1L14
TKC 5089	LIGHT SWITCH	1L15
TKC 5115	FUEL PUMP	1I06
TKC 5168	CLIP	1L14
TKC 5181	BRACKET	1M03
TKC 5244	UPPER BRACKET	1I07
TKC 5317	LAYSHAFT GEAR-5THSPEED	1E05
TKC 5318	LAYSHAFT CLUSTER GEAR	1E05
TKC 5356	CLUTCH OPERATING LEVER	1D03
TKC 5360	OIL COLLECTOR	1E03
TKC 5427	GEARCHANGE HOUSING ASSY	1E06
TKC 5481	CRADLE ASSY	1K03
TKC 5532	THERMOSTATIC SWITCH	1K02
TKC 5543	RADIATOR THERMOSTAT CABLE	1M03
TKC 5558	STRAP	1M03
TKC 5558	STRAP	1K02
TKC 5564	CRADLE ASSY	1K02
TKC 5584	LABEL	2C04
TKC 5588	BRACKET-CARBON CANISTERS	1J06
TKC 5634	BRACKET	1L14
TKC 5638	ENGINE HARNESS PI	1M02
TKC 5716	IGNITION HARNESS PI	1M03
TKC 5780	BOLT-COLUMN TO BODY	1E02
TKC 5819	BRACKET	1I12
TKC 5913	ENGINE HARNESS	1M02
TKC 5914	ENGINE HARNESS	1M02
TKC 5926	SUPPORT STRAP	1E06

2609

PART NUMBER	DESCRIPTION	REF.NO.
TKC 5990	HOSE-HEATER	1K04
TKC 5993	WATER SHIELD	1L15
TKC 5993	WATER SHIELD	1L17
TKC 6000	BATTERY CABLE	1M06
TKC 6093	MOULDING-FUEL PUMP	1I12
TKC 6094	MOULDING-FUEL PUMP	1I12
TKC 6097	BUSH	1F02
TKC 6220	BATTERY CABLE	1M06
TKC 6254	FOGLAMP SWITCH	1L14
TKC 6254	FOGLAMP SWITCH	1L15
TKC 6256	GAUGE UNIT PETROL TANK	1I06
TKC 6340	HOSE-FILTER TO FUEL PIPE	1I11
TKC 6341	HOSE-REGULATOR TO SPILL	1I11
TKC 6343	HOSE-FUEL FEED	1I10
TKC 6343	HOSE-FUEL FEED PIPE TO ENGINE	1I11
TKC 6348	HOSE	1I11
TKC 6351	HOSE-FUEL FEED	1I10
TKC 6355	HOSE	1I11
TKC 6369	HOSE-FUEL TANK TO PUMP	1I11
TKC 6371	HOSE FUEL TANK TO PUMP	1I11
TKC 6424	GEARLEVER ASSEMBLY	1E06
TKC 6802	REVERSE LIGHTSWITCH	1E06
TL 11	OLIVE	1J03
TL 11	OLIVE	1J06
TN 3209	NUT	1C11
UKC 7	10" RING-GEAR SELECTOR SHAFT	1E05
UKC 8	REAR BEARING CONSTANT PINION	1E03
UKC 12	OIL SEAL-GEARBOX FRONT COVER	1E05
UKC 13	PIVOT PIN	1E03
UKC 18	PIN	1E05
UKC 25	SPACER	1E03
UKC 26	PLUG OIL FILLER	1E05
UKC 26	PLUG	1F04
UKC 31	SPRING	1E03
UKC 31	SYNCHRO SPRING	1E04
UKC 37	SYNCHRO SPACER	1E03
UKC 58	DISTANCE PIECE	1E05
UKC 73	CIRCLIP	1E04
UKC 75	PLUG SPRING RETAINING	1E04
UKC 82	TOP SPRING INSULATOR	1F05
UKC 89	CABLE CONNECTOR	1M06
UKC 101	BUSH	1E03
UKC 101	PEDAL BUSH	1M04
UKC 104	SHAFT	1E03
UKC 104	PEDAL SHAFT	1M04

2609

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L-M		



PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
UKC 113	SPRING	1003	UKC 972	THRUST WASHER DIFF PINION (1.60/1.65MM)	1F04
UKC 113	RETURN SPRING	1M04	UKC 975	GEAR	1F04
UKC 133	ROLLER BEARING	1E05	UKC 976	GEAR	1F04
UKC 166	FRONT COVER ASSEMBLY	1E03	UKC 979	SPACER	1F04
UKC 169	BEARING CONSTANT PINION	1E03	UKC 981	ROLLER BEARING	1F04
UKC 169	FRONT BEARING CONSTANT PINION	1E04	UKC 982	BEARING SHIP (2.85MM)	1F04
UKC 170	HOLLOW COWEL	1E02	UKC 984	BEARING SHIM (2.93MM)	1F04
UKC 174	FULCRUM-COMPENSATOR	1M07	UKC 986	BEARING SHIM (3.01MM)	1F04
UKC 186	CLUTCH MASTER CYLINDER	1D04	UKC 988	BEARING SHIP (3.09MM)	1F04
UKC 208	BUSH	1F02	UKC 990	BEARING SHIP (3.17MM)	1F04
UKC 214	SPECIAL WASHER	1F02	UKC 992	BEARING SHIP (3.21MM)	1F04
UKC 219	GEAR	1F04	UKC 994	BEARING SHIM (3.33MM)	1F04
UKC 255	PACKING STRIP	1113	UKC 996	BEARING SHIP (3.41MM)	1F04
UKC 255	PACKING STRIP	1106	UKC 1060	SEAL-FRONT COVER	1E03
UKC 269	BEARING SHIM (1.25MM)	1F04	UKC 1086	CLIP	1D04
UKC 271	BEARING SHIP (1.35MM)	1F04	UKC 1088	WASHER	1E05
UKC 273	BEARING SHIM (1.45MM)	1F04	UKC 1091	DISTANCE PIECE	1E05
UKC 275	BEARING SHIM (1.55MM)	1F04	UKC 1101	BUMP STOP	1F03
UKC 277	BEARING SHIM (1.65MM)	1F04	UKC 1108	LOWER SPRING INSULATOR	1F05
UKC 279	BEARING SHIP (1.75MM)	1F04	UKC 1145	D WASHER	1F02
UKC 307	LOWER MOUNTING RUBBER	2C02	UKC 1146	PACKING WASHER	1M02
UKC 308	SPACER	2C02	UKC 1413	NUT	1J03
UKC 309	SPACER	2C02	UKC 1413	NUT	1J06
UKC 310	RETAINER	2C02	UKC 1468	STUD	1113
UKC 329	THRUST COLLAT	1F03	UKC 1468	STUD	1J06
UKC 429	ACCELERATOR LHS	1104	UKC 1469	PACKING STRIP	1113
UKC 433	MOUNTING BRACKET	1104	UKC 1669	PACKING STRIP	1106
UKC 493	GASKET TAIL LAMP BASE	1L10	UKC 1664	GEAR AND BUSH ASSY	1E05
UKC 519	REAR PARKER LAMP	1L10	UKC 1655	COVER-ALTERNATOR	1L04
UKC 628	SPRING INSULATOR	1F03	UKC 1689	WASHER LAYSHAFT GEAR	1E05
UKC 683	SPACER REVERSE IDLER SHAFT	1E05	UKC 1690	CIRCLIP	1E05
UKC 703	UPPER LINK ASSY	1F05	UKC 1743	UPPER RESTRICTOR PLATE	1E15
UKC 772	SLIPPER PAD REVERSE LEVER	1E05	UKC 1744	DISTANCE PIECE	1E15
UKC 823	NUT	1F04	UKC 1757	MOUNTING BRACKET	1E15
UKC 854	BUSH	1E05	UKC 1806	CLIP (PUSH ROD TO LEVER)	1E03
UKC 854	BUSH	1E05	UKC 1932	CLIP-HAZARD UNIT	1M06
UKC 963	BOLT (CROWN WHEEL AND PINION)	1F04	UKC 2031	B POST STRIKER	2C09
UKC 964	THRUST WASHER DIFF PINION (1.17/1.22MM)	1F04	UKC 2072	OIL FEED RING	1E05
UKC 965	THRUST WASHER DIFF PINION (1.24/1.30MM)	1F04	UKC 2089	PIVOT PIN	1E04
UKC 966	THRUST WASHER DIFF PINION (1.30/1.35MM)	1F04	UKC 2105	CIRCLIP	1E04
UKC 967	THRUST WASHER DIFF PINION (1.45/1.40MM)	1F04	UKC 2209	LOWER RESTRICTOR PLATE	1E15
UKC 968	THRUST WASHER DIFF PINION (1.40/1.45MM)	1F04	UKC 2213	WHEEL STUD	1F04
UKC 969	THRUST WASHER DIFF PINION (1.45/1.50MM)	1F04	UKC 2225	MOUNTING RUBBER	1K02
UKC 970	THRUST WASHER DIFF PINION (1.50/1.55MM)	1F04	UKC 2257	SEPARATOR CANISTER	1J07
UKC 971	THRUST WASHER DIFF PINION (1.55/1.60MM)	1F04	UKC 2257	SEPERATOR CANISTER	1J05

2610

2610

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - 2A		

2610

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
UKC 2271	REAR SILENCER SUPPORT BRACKET	1117	UKC 3530	SHIFTING PLATE	1E04
UKC 2274	STRAP-REAR SILENCER	1117	UKC 3531	SHIFTING PLATE	1E04
UKC 2322	LOWER BEARING (UPPER STEERING COLUMN)	1602	UKC 3550	VALVE BRACKET	1M05
UKC 2323	CLAMP	1602	UKC 3660	PLATE ASSEMBLY	1E04
UKC 2381	SPRING-GEAR LEVER	1E14	UKC 3696	PLATE ASSY	1E04
UKC 2404	EXHAUST SUPPORT BRACKET ASSY	1117	UKC 3740	HANDBRAKE ASSY	1M06
UKC 2408	CLOCK	1L13	UKC 3771	OIL DRAIN PLUG	1E02
UKC 2409	PRINTED CIRCUIT	1L13	UKC 3775	CONNECTOR	1I05
UKC 2410	SPEEDO RESET	1L13	UKC 3775	DOUBLE ENDED UNION	1I11
UKC 2413	CLOCK RESET CABLE	1L13	UKC 3776	FLARE NUT	1I05
UKC 2416	RELAY	1M06	UKC 3787	NUT	1E14
UKC 2427	BACKLIGHT FEED	1M03	UKC 3794	CLIP	1I09
UKC 2428	EXTENSION LEAD	1M03	UKC 3794	HOSE CLIP	1J04
UKC 2449	UNIVERSAL JOINT	1G02	UKC 3795	CLIP	1I05
UKC 2643	CHECK VALVE	1J04	UKC 3795	HOSE CLIP	1I11
UKC 2656	BREATHER BODY	1E02	UKC 3795	CLIP	1J05
UKC 2662	PIVOT PIN REVERSE LEVER	1E05	UKC 3795	HOSE CLIP	1J07
UKC 2663	NEEDLE BEARING	1E04	UKC 3798	HOSE CLIP	1I11
UKC 2841	HOSE-SEPARATOR CANISTER	1J07	UKC 3798	CLIP	1J02
UKC 2841	HOSE	1J05	UKC 3798	HOSE CLIP	1J04
UKC 2852	HOSE	1J07	UKC 3799	CLIP HOSE	1I11
UKC 2853	HOSE	1I05	UKC 3799	HOSE CLIP	1J02
UKC 2936	BUTTON BODY-GEARLEVER	1E14	UKC 3822	BACK CASE-INSTRUMENT PANEL	1L13
UKC 2940	HOUSING GASKET	1E04	UKC 3826	INSTRUMENT UNIT LENS	1L13
UKC 2941	SELECTOR GATE PLATE	1E14	UKC 3831	NUT	1E15
UKC 2942	BUTTON-GEARLEVER	1E14	UKC 3835	NUT	1I14
UKC 2986	KNOB-GEARLEVER	1E14	UKC 3835	NUT	1I16
UKC 3004	GEAR LEVER KNOB	1E06	UKC 3877	COUPLING FLANGE	1E04
UKC 3011	YOKE SHAFT TO GEAR LEVER	1E04	UKC 3909	SUPPORT PLATE SYNCHRO HUB	1E04
UKC 3014	NUT (FUSE BOX ATTACHMENT)	1M06	UKC 391E	LEVER GRIP	1M06
UKC 3016	PAD - STEERING WHEEL	1E02	UKC 3949	OIL SEAL-GEARBOX EXTENSION CASE	1E04
UKC 3027	BREATHER CAP	1E02	UKC 3951	BRACKET	1E05
UKC 305	SCREW	1E04	UKC 4003	SUPPORT BRACKET	1M04
UKC 30	BUSH BRACKET	1E02	UKC 4208	HARNES CLIP	1E06
UKC 31	MOUNTING BRACKET	1E05	UKC 4227	FRONT ENGINE MTG BRKT RH	1C11
UKC 3152	SHAFT AND PIN ASSY	1E05	UKC 4231	FRONT ENGINE MTG BRKT LH	1C11
UKC 3159	DUST CAP (GEAR LEVER)	1E06	UKC 4293	NUT	1E04
UKC 3180	P-CLIP	1M05	UKC 4341	OLIVE-EXHAUST PIPE	1I14
UKC 3193	BUSH-GEAR CHANGE HOUSING	1E06	UKC 4343	STUD PLATE	1E15
UKC 3238	RETAINER	1E06	UKC 4389	JACK HANDLE	2E02
UKC 3262	SPACER	1M03	UKC 4472	SUPPORT BRACKET FRONT EXHAUST PIPE (MANUAL)	1I16
UKC 3336	COLLAR (5TH SPEED GEAR)	1E04	UKC 4473	SUPPORT BRACKET FRONT EXHAUST PIPE (AUTO)	1I16
UKC 3393	MIRROR ASSY	2C13	UKC 4498	GROMMET	1M05
UKC 3413	AIR CON OUT OUT SWITCH	1L15	UKC 4652	SPEEDO CABLE	1L14
UKC 3530	SHIFTING PLATE	1E03	UKC 4837	BOLT	1M02

2611

2611

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Facia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - 1S		

2611

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
UKC 4981	DAMPER GAITER	1F03	UKC 6724	HOSE CLIP	1K02
UKC 4995	OIL SEAL (HYPOID PINTON)	1F04	UKC 6729	BUMP RUBBER (REAR SUSPENSION)	1F05
UKC 5001	REVERSE BAULK PLATE	1E06	UKC 6797	NUT (FLANGE FIXING)	1E04
UKC 5002	BACKING PLATE REVERSE BAULK	1E06	UKC 6877	WHEEL BADGE	1F06
UKC 5003	SPACER REVERSE BAULK	1E06	UKC 7074	FLANGE NUT	1F04
UKC 5025	SPRING REVERSE BAULK	1E06	UKC 7147	BEZEL	1L15
UKC 5042	UPPER SPRING PAN	1F03	UKC 7180	FIXING PLATE	1I16
UKC 5118	HOSE CLIP	1M04	UKC 7197	WHEEL NUT	1F06
UKC 5256	BRACKET ASSY (BRAKE PIPE)	1F04	UKC 7252	ABUTMENT WASHER	1E04
UKC 5278	GAITER (HANDBRAKE LEVER)	1M07	UKC 7257	HOSE-HEATER	1K04
UKC 5377	SELECTOR SHAFT PIN	1E04	UKC 7310	FRONT HUB ASSY	1K02
UKC 5394	TORSION SPRING	1E06	UKC 7385	HEATSHIELD	1I06
UKC 5400	RETAINER BRACKET	1E06	UKC 7385	HEATSHIELD	1I15
UKC 5424	CLIP SLEEVE	1E06	UKC 7463	HEATSHIELD ASSY RH-FEDERAL	1I16
UKC 5480	RUBBER BUSH	1K03	UKC 7464	HEATSHIELD ASSY LH-FEDERAL	1I16
UKC 5481	SPACER	1K03	UKC 7495	LOWER CONE	1F03
UKC 5508	SPRING THRUST WASHER	1E02	UKC 7641	BATTERY EARTH CABLE	1M04
UKC 5514	LINK BUSH	1F05	UKC 7711	CLAMP	1I14
UKC 5615	SPRING INSULATOR	1F03	UKC 7712	UNDERSHIELD	1I14
UKC 5720	EXTENSION LEAD	1M08	UKC 7713	REINFORCEMENT	1I14
UKC 5843	SYNCHRO ASSEMBLY (3RD/4TH GEARS)	1E03	UKC 7783	SPEEDO CABLE	1L14
UKC 5844	SYNCHRO ASSEMBLY (5TH GEAR)	1E04	UKC 7817	BRACKET	1K03
UKC 5850	SYNCHRO ASSEMBLY (1ST/2ND SPEED)	1E04	UKC 7832	HEATSHIELD ASSY REAR RH-FEDERAL	1I16
UKC 5871	GASKET	1D04	UKC 7836	HEATSHIELD ASSY REAR LH-FEDERAL	1I16
UKC 5912	WIPER ARM LH LHS	1L11	UKC 7840	PIN	1I04
UKC 5914	WIPER ARM RH LHS	1L11	UKC 7840	PIN	2C12
UKC 5936	FRONT WING PARKER LAMP	1L10	UKC 7842	HEATSHIELD RH-CATALYST	1I14
UKC 6338	SEAT SENSOR	1L16	UKC 7857	LABEL-SUN VISOR	2D08
UKC 6469	LABEL	2C04	UKC 7925	SPECIAL WASHER	2C02
UKC 6482	ACCELERATOR CABLE LHS	1I04	UKC 7948	CLAMP PLATE	1I07
UKC 6512	STOP BRACKET LH	1F04	UKC 7949	CLAMP PLATE ASSY	1K02
UKC 6513	STOP BRACKET RH	1F04	UKC 7951	LOWER SHAFT ASSEMBLY	1E02
UKC 6519	PIPE CLIP	1E14	UKC 7979	BRACKET	1D04
UKC 6540	CIRCLIP	1E04	UKC 7980	BRACKET	1D04
UKC 6684	CABLE STRAP	1M05	UKC 7988	ROUTING BRACKET RH	1K02
UKC 6722	HOSE CLIP	1G05	UKC 8089	REVERSE LIGHT SWITCH	1E04
UKC 6722	HOSE CLIP	1I02	UKC 8197	RUBBER BUSH	1F02
UKC 6722	HOSE CLIP	1I08	UKC 8268	BUMP STOP	1E15
UKC 6722	HOSE CLIP	1K03	UKC 8268	BUMP STOP	2943
UKC 6722	HOSE CLIP	1K02	UKC 8328	CLAMP	1I16
UKC 6723	HOSE CLIP	1J05	UKC 8330	FRONT ENGINE MTC	1C11
UKC 6723	HOSE CLIP	1J06	UKC 8340	UNDERSHIELD REAR RH-FEDERAL	1I16
UKC 6723	HOSE CLIP	1K03	UKC 8341	UNDERSHIELD REAR LH-FEDERAL	1I16
UKC 6723	HOSE CLIP	1K04	UKC 8343	BOOT LAMP HARNESS	1M03
UKC 6723	RADIATOR CLIP	1K02	UKC 8344	IGNITION HARNESS	1M03

2612

2612

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Facia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - M		

2612

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
UKC 8346	STARTER CABLE	1M06	UKC 8572	BRACKET-OIL COOLER	1E14
UKC 8347	BRIDGE PIECE	1I14	UKC 8581	UNDERSHIELD-JUNCTION	1I14
UKC 8348	U BOLT	1I14	UKC 8590	BRACKET-OIL COOLER	1E14
UKC 8349	CLAMP	1I14	UKC 8598	HEAT SHIELD	1E04
UKC 8354	ENGINE HARNESS	1M02	UKC 8617	HOSE	1E05
UKC 8364	CATALYST HEATSHIELD ASSY RH	1I14	UKC 8676	U BOLT	1I16
UKC 8368	UNDERSHIELD	1I14	UKC 8712	UNDERSHIELD	1I14
UKC 8369	REINFORCEMENT	1I14	UKC 8768	ACCELERATOR PEDAL	1I06
UKC 8370	CLAMP	1I14	UKC 8820	BANJO BOLT	1E05
UKC 8375	DOWNPIPE HEATSHIELD ASSY RH	1I14	UKC 8821	SEAL	1E05
UKC 8376	DOWNPIPE HEATSHIELD ASSY LH	1I14	UKC 9855	RETAINER PLATE	1M03
UKC 8377	EXHAUST CLAMP	1I14	UKC 8877	WASHER	1E07
UKC 8378	BRIDGE-EXHAUST	1I14	UKC 8908	HOSE	1E07
UKC 8413	SPACER	1E15	UKC 8942	COMPRESSOR HARNESS	1M02
UKC 8413	SPACER	2E43	UKC 8982	OIL PIPE-GEARBOX PUMP	1E05
UKC 8454	PIPE ASSY	1E04	UKC 8996	WASHER 5.10PP	1E04
UKC 8455	HOSE	1E04	UKC 8998	WASHER 5.16PP	1E04
UKC 8456	PIPE ASSY	1E04	UKC 9000	WASHER 5.22PP	1E04
UKC 8459	MOUNTING BRACKET LH	1K02	UKC 9002	WASHER 5.28PP	1E04
UKC 8466	SELECTIVE WASHER PINION(1.60MM)	1E03	UKC 9004	WASHER 5.34PP	1E04
UKC 8468	SELECTIVE WASHER PINION(1.75MM)	1E03	UKC 9006	WASHER 5.40PP	1E04
UKC 8470	SELECTIVE WASHER PINION(1.81MM)	1E03	UKC 9008	WASHER 5.46PP	1E04
UKC 8472	SELECTIVE WASHER PINION(1.87MM)	1E03	UKC 9010	WASHER 5.52PP	1E04
UKC 8474	SELECTIVE WASHER PINION(1.93MM)	1E03	UKC 9012	WASHER 5.58PP	1E04
UKC 8476	SELECTIVE WASHER PINION(1.99MM)	1E03	UKC 9014	WASHER 5.64PP	1E04
UKC 8478	SELECTIVE WASHER PINION(2.05MM)	1E03	UKC 9035	PIPE FUEL SYSTEM	1E05
UKC 8480	SELECTIVE WASHER PINION(2.11MM)	1E03	UKC 9081	SELECTIVE WASHER PINION(1.39MM)	1E03
UKC 8482	SELECTIVE WASHER PINION(2.17MM)	1E03	UKC 9083	SELECTIVE WASHER PINION(1.45MM)	1E03
UKC 8484	SELECTIVE WASHER PINION	1E03	UKC 9085	SELECTIVE WASHER PINION(1.51MM)	1E03
UKC 8486	SELECTIVE WASHER PINION	1E03	UKC 9087	SELECTIVE WASHER PINION(1.57MM)	1E03
UKC 8488	SELECTIVE WASHER PINION	1E03	UKC 9089	SELECTIVE WASHER PINION(1.63MM)	1E03
UKC 8490	SELECTIVE WASHER PINION	1E03	UKC 9174	CLAMP-SUPPORT BRACKET	1E05
UKC 8492	SELECTIVE WASHER PINION	1E03	UKC 9189	CLAMP	1E02
UKC 8494	SELECTIVE WASHER PINION	1E03	UKC 9197	GEAR LEVER ASSY	1E04
UKC 8496	SELECTIVE WASHER PINION	1E03	UKC 9205	GEARBOX HARNESS	1M02
UKC 8499	SELECTIVE WASHER LAYSHAFT (1.69MM)	1E05	UKC 9244	HEATSHIELD LH-CATALYST	1I14
UKC 8501	SELECTIVE WASHER LAYSHAFT (1.75MM)	1E05	UKC 9249	CATALYST HEATSHIELD ASSY LH	1I14
UKC 8503	SELECTIVE WASHER LAYSHAFT (1.81MM)	1E05	UKC 9338	SEAT-GEARLEVER AND SELECTOR ROD	1E04
UKC 8505	SELECTIVE WASHER LAYSHAFT (1.87MM)	1E05	UKC 9350	NUMBER PLATE LAMP HARNESS	1M07
UKC 8507	SELECTIVE WASHER LAYSHAFT (1.93MM)	1E05	UKC 9395	THRUST RUBBER	1E03
UKC 8509	SELECTIVE WASHER LAYSHAFT (1.99MM)	1E05	UKC 9420	WASHER-LAYSHAFT(2.29MM)	1E05
UKC 8511	SELECTIVE WASHER LAYSHAFT (2.05MM)	1E05	UKC 9422	WASHER-LAYSHAFT(2.35MM)	1E05
UKC 8513	SELECTIVE WASHER LAYSHAFT (2.11MM)	1E05	UKC 9424	WASHER-LAYSHAFT(2.41MM)	1E05
UKC 8515	SELECTIVE WASHER LAYSHAFT (2.17MM)	1E05	UKC 9426	WASHER-LAYSHAFT(2.47MM)	1E05
UKC 8517	SELECTIVE WASHER LAYSHAFT (2.23MM)	1E05	UKC 9430	BOSS	1M02

2613

2613

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers, etc. Instruments	1L-M		



PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
UKC 9435	BEARING SHIM (2.09MM)	1F04	ULC 2242	BRACKET	1L15
UKC 9437	BEARING SHIM (2.77MM)	1F04	ULC 2242	BRACKET	1L17
UKC 9439	BEARING SHIM (3.49MM)	1F04	ULC 2246	HOSE	1J06
UKC 9541	BEARING SHIM (3.57MM)	1F04	ULC 2250	HOSE	1J06
UKC 9570	BOLT TIE ROD LEVER TO STUB AXLE	1F02	ULC 2338	CLIP	1I07
UKC 9571	BOLT	1M02	ULC 2350	COLLAR	1F04
UKC 9572	BOLT	1M02	ULC 2360	ACCELERATOR CABLE P.L.I	1I04
UKC 9591	SUPPORT BRACKET	1M05	ULC 2362	CIRCLIP	1F04
UKC 9601	P CLIP	1K02	ULC 2435	MOUNTING CUP	1F03
UKC 9754	MOUNTING RUBBER	1I12	ULC 2445	BEARING-CONSTANT PINION	1M03
UKC 9846	REVERSE LIGHT SWITCH	1E06	ULC 2446	GROMMET	1I07
UKC 9859	BRACKET ASSEMBLY	1J05	ULC 2447	SPACER	1I07
UKC 9955	LEVER-SELECTOR CONTROL ROD	1E14	ULC 2487	SUPPORT BRACKET	1F03
ULC 1049	ENGINE EARTH LEAD	1M06	ULC 2524	CHECKSTRAP	1I12
ULC 1116	CROSS PIN	1F04	ULC 2643	RUBBER SEAL	1F03
ULC 1200	FINGER-GEAR LEVER	1E14	ULC 2730	PIPE CLIP	1E14
ULC 1201	FRONT COVER ASSY	1E03	ULC 2820	ENGINE EARTH LEAD	1M06
ULC 1284	GASKET-GEARCASE TO FRONT COVER	1E03	ULC 2841	CLIP-FILTER AND PUMP	1I12
ULC 1301	ATTACHMENT PLATE	1J05	ULC 2964	GEARCASE AND CENTRE PLATE	1E02
ULC 1579	FRONT BUSH	1F05	ULC 2999	PAD-STEERING WHEEL	1E02
ULC 1580	REAR BUSH	1F05	ULC 3085	BRACKET	1E14
ULC 1597	RETAINER PLATE	1K02	ULC 3105	BACKPLATE	1L16
ULC 1621	MOUNTING RUBBER	1K02	ULC 3163	CLAMP PLATE ASSY	1I07
ULC 1645	LABEL-EMISSION INFORMATION	2C07	ULC 3209	GEARLEVER KW02	1E06
ULC 1776	BEARING-LAYGEAR	1E05	ULC 3248	NUT	1E06
ULC 1826	DRAIN TUBE	1E03	ULC 4099	GEAR AND BUSH ASSY(REVERSE)	1E05
ULC 2044	GEARCASE AND CENTRE PLATE ASSY	1E02	WA 104001	WASHER	1L10
ULC 2045	GEARCASE AND CENTRE PLATE ASSY	1E02	WA 104001	WASHER	1K03
ULC 2087	BRACKET P CLIP	1E07	WA 104001	WASHER	1L12
ULC 2101	SEALING STRIP	1K02	WA 104001	WASHER	1L16
ULC 2102	SEALING STRIP	1K02	WA 104001	WASHER	1M07
ULC 2103	AIR BLEED HOSE A/C	1K02	WA 104001	WASHER	2C16
ULC 2104	AIR BLEED HOSE	1K02	WA 104001	WASHER	2C04
ULC 2105	AIR BLEED HOSE A/C	1K02	WA 104004	WASHER	1M08
ULC 2106	AIR BLEED HOSE A/C	1K03	WA 105001	WASHER	1I08
ULC 2106	AIR BLEED HOSE	1K02	WA 105001	WASHER	1I12
ULC 2106	AIR BLEED HOSE	1K03	WA 105001	WASHER	1I15
ULC 2109	BALANCE WEIGHT	1F06	WA 105001	WASHER	1K03
ULC 2122	OVERFLOW HOSE	1K02	WA 105001	WASHER	1L09
ULC 2122	OVERFLOW HOSE	1K03	WA 105001	WASHER	2C03
ULC 2147	LABEL	2C04	WA 105001	WASHER	2C08
ULC 2148	LABEL	2C04	WA 105001	WASHER	2C03
ULC 2231	SUPPORT BRACKET	1M03	WA 105001	WASHER	2C08
ULC 2239	BRACKET	1I11	WA 105004	WASHER	2C12
ULC 2241	MOUNTING RUBBER	1I11	WA 105051	WASHER	1I11

2614

2614

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I - J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers, Wipers, Instruments **1L - M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2G14

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
WA 106001	WASHER	1K03	WE 105001	WASHER	1E05
WA 108041	WASHER	1G02	WE 105001	WASHER	1E14
WA 108041	WASHER	1K02	WE 103001	WASHER	1M04
WA 108054	WASHER	2D10	WE 106001	WASHER	1M05
WA 108101	WASHER	1G02	WE 103001	WASHER	1M06
WA 108151	WASHER	1M06	WF 513	WASHER	1E02
WA 112081	WASHER	1Q03	WF 513	WASHER	1E05
WA 702121	WASHER	1L15	WF 513	WASHER	1F04
WA 702121	WASHER	1L17	WF 104001	WASHER	2C16
WA 707101	WASHER	1E12	WF 105001	WASHER	2D12
WB 106041	WASHER	1L09	WF 112001	WASHER LOCK	1D04
WB 106141	WASHER	1C08	WF 702101	WASHER	2D10
WB 108051	WASHER	1M06	WH 105041	NUT	1E16
WB 108051	WASHER	1L09	WKC 26	BATTERY TRAY PANEL LHS	2C04
WB 110061	WASHER	1L09	WKC 34	DRIP CHANNEL LH	2C05
WC 104001	WASHER	1L16	WKC 35	DRIP CHANNEL RH	2C06
WC 105001	WASHER	1E15	WKC 64	REAR QUARTER PANEL LH	2C11
WC 105001	WASHER	1E14	WKC 65	REAR QUARTER PANEL RH	2C11
WC 105001	WASHER PLAIN PIN	1M03	WKC 79	TONNEAU LOWER PANEL LH	2C11
WC 105001	WASHER	1M04	WKC 80	TONNEAU LOWER PANEL RH	2C11
WC 105001	WASHER	2C15	WKC 81	ROOF PANEL ASSY	2C06
WC 105004	WASHER	2D10	WKC 86	FRONT LOWER PANEL	2C06
WC 106001	WASHER	2C16	WKC 99	CLOSING PANEL-ROOF BACKLIGHT	2C06
WC 106041	WASHER	1G04	WKC 114	WEATHERSTRIP BACKLIGHTS	2C13
WC 106041	WASHER	1E07	WKC 135	SIDE PANEL LH	2C12
WC 106041	WASHER	2C03	WKC 145	SPARE WHEEL PANEL	2C12
WC 106041	SCREW	2C08	WKC 174	REAR SIDEMEMBER LH	2C12
WC 106041	WASHER	2C12	WKC 175	REAR SIDEMEMBER RH	2C12
WC 106041	WASHER	2C15	WKC 199	ROOF PANEL ASSY-TUNROOF	2C06
WC 108055	WASHER	1E07	WKC 207	LOWER CLOSING PANEL LH	2C12
WC 110061	WASHER	1G03	WKC 208	LOWER CLOSING PANEL RH	2C12
WC 110061	WASHER	1E07	WKC 252	REAR BUMPER ASSY	2C15
WC 110061	WASHER	1E07	WKC 254	SCREEN SURROUND FINISHER LH	2C13
WC 110061	WASHER	2C14	WKC 255	SCREEN SURROUND FINISHER RH	2C13
WC 112081	WASHER	1F02	WKC 271 LG	CUBBY BOX LID	2C03
WC 703081	WASHER	2D04	WKC 271 PA	CUBBY BOX LID ASSEMBLY	2C03
WC 704061	WASHER	1L11	WKC 337	DRIP CHANNEL MOULDING LH	2C15
WD 159	WASHER	2C03	WKC 338	DRIP CHANNEL MOULDING RH	2C15
WD 159	WASHER	2C12	WKC 340	LOWER FINISHER	2C13
WD 106041	WASHER	2C12	WKC 382 LG	FAZIA BASE MOULDING	2C02
WD 108051	WASHER	2C02	WKC 382 PA	FAZIA BASE MOULDING LHS	2C02
WE 120001	WASHER	1F02	WKC 422 LG	INSTRUMENT UPPER ROLL	2C03
WE 605	STARWASHER	1E14	WKC 422 PA	INSTRUMENT UPPER ROLL LHS (HARD)	2C03
WE 605	STAR WASHER	1L10	WKC 450	DIVISION CHANNEL LH	2C08
WE 605	WASHER	2D15	WKC 460	DIVISION CHANNEL RH	2C08

2615

2615

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I - J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers-Wipers, Instruments **1L - M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2G15

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
WKC 481 LE	A POST Moulding LH	2005	WKC 3534 PA	REAR QUARTER TRIMBOARD RH	2005
WKC 481 PA	A POST Moulding LH	2005	WKC 3535 PA	BACKLIGHT COVER	2007
WKC 491 LE	A POST Moulding RH	2005	WKC 3545 RA	FRONT SEAT ASSY LH	2012
WKC 491 PA	A POST Moulding RH	2005	WKC 3545 RB	FRONT SEAT ASSY LH	2012
WKC 531 LE	FRONT CONSOLE Moulding	2004	WKC 3546 RA	FRONT SEAT ASSY RH	2012
WKC 531 PA	FRONT CONSOLE Moulding	2004	WKC 3546 RB	FRONT SEAT ASSY RH	2012
WKC 550	REAR QUARTER GRILLE LH	2016	WKC 3561	FRONT LUGGAGE FLOOR PANEL	2012
WKC 570	REAR QUARTER GRILLE RH	2016	WKC 3591	WHEELARCH INNER PANEL LH	2011
WKC 1200	HEADLAMP BEZEL LH	1003	WKC 3592	WHEELARCH INNER PANEL RH	2011
WKC 1201	HEADLAMP BEZEL RH	1003	WKC 3617	WHEELARCH UPPER PANEL LH	2011
WKC 1230	HEADLAMP BOX LH (PRIMER)	2003	WKC 3618	WHEELARCH UPPER PANEL RH	2011
WKC 1232	HEADLAMP BOX RH (PRIMER)	2003	WKC 3619	WHEELARCH LOWER PANEL LH	2011
WKC 1295 AA	SEAT ASSY LH BEIGE	2012	WKC 3620	WHEELARCH LOWER PANEL RH	2011
WKC 1296 AA	SEAT ASSY RH BEIGE	2012	WKC 3631	RADIATOR BLANKING BOARD	1K02
WKC 1555	A POST LOWER LH	2005	WKC 3643	COVER FRONT HOOD LINKAGE LH	2011
WKC 1556	A POST LOWER RH	2005	WKC 3644	COVER FRONT HOOD LINKAGE RH	2011
WKC 1670 AA	BACKLIGHT COVER	2007	WKC 3645	COVER REAR HOOD LINKAGE LH	2011
WKC 2448	WHEELARCH OUTER PANEL LH	2004	WKC 3646	COVER REAR HOOD LINKAGE RH	2011
WKC 2449	WHEELARCH OUTER PANEL RH	2004	WKC 3659	DOOR ASSY LH	2007
WKC 2649	SIDE CHANNEL LH	2010	WKC 3660	DOOR ASSY RH	2007
WKC 2650	SIDE CHANNEL RH	2010	WKC 3664	HANDBRAKE HEATSHIELD	1007
WKC 2652 PA	SUNSHINE ROOF	2002	WKC 3671	FOLDING HOOD ASSY	2011
WKC 3295	Moulding LH	2012	WKC 3672	FOLDING HOOD ASSY	2011
WKC 3296	Moulding RH	2012	WKC 3683	FOLDING HOOD ASSY	2011
WKC 3298 AB	TANK COVER TRIM ASSY	2008	WKC 3687	HOOD FRAME ASSY	2010
WKC 3298 JJ	TANK COVER TRIM ASSY	2008	WKC 3688 AP	SEWN HOOD ASSY	2011
WKC 3298 PA	TANK COVER TRIM ASSY	2008	WKC 3688 JJ	SEWN HOOD ASSY	2011
WKC 3308	INSULATION PAD	2017	WKC 3688 PR	SEWN HOOD ASSY	2011
WKC 3340	INSULATION PAD	2016	WKC 3672	FRONT CROSSMEMBER PANEL	2004
WKC 3469	QTR PANEL INNER LH	2011	WKC 3673	FRONT GRILLE LH	2015
WKC 3470	QTR PANEL INNER RH	2011	WKC 3674	FRONT GRILLE RH	2015
WKC 3499	A POST UPPER LH	2005	WKC 3755 LG	FACIA BASE Moulding P/I	2002
WKC 3500	A POST UPPER RH	2005	WKC 3800 AA	REAR PARCEL SHELF	2007
WKC 3511	DOOR ASSY RH	2007	WKC 3800 PA	REAR PARCEL SHELF	2007
WKC 3512	DOOR ASSY LH	2007	WKC 3806 AD	FRONT CARPET RH-CHESTNUT	2014
WKC 3513	CLOSING PANEL LH	2011	WKC 3809 AD	FRONT CARPET LH-CHESTNUT	2014
WKC 3514	CLOSING PANEL RH	2011	WKC 3817 AD	GEARBOX CARPET-CHESTNUT	2014
WKC 3515	B POST ASSY LH	2011	WKC 3819 AD	REAR CARPET LH-CHESTNUT	2014
WKC 3516	B POST ASSY RH	2011	WKC 3820 AD	REAR CARPET RH-CHESTNUT	2014
WKC 3517	TONGUEAU SIDE PANEL LH	2011	WKC 3821 AD	SILL CARPET LH-CHESTNUT	2014
WKC 3518	TONGUEAU SIDE PANEL RH	2011	WKC 3822 AD	SILL CARPET RH-CHESTNUT	2014
WKC 3526	DASH INSULATION PAD LH LHS	2016	WKC 3827 PA	DOOR SEAL	2005
WKC 3527	DASH INSULATION PAD RH LHS	2016	WKC 3897	FRONT BUMPER ASSY	2014
WKC 3528	INSULATION PAD	2016	WKC 3922 PR	BULKHEAD TRIMPAD	2007
WKC 3533 PA	REAR QUARTER TRIMBOARD LH	2005	WKC 3923	CANTRAIL ASSY LH	2005

2616

2616

GROUP INDEX

Introduction
 Engine
 Flywheel and Clutch
 Gearbox and Propshaft
 Axles, Suspension, Drive Shafts, Wheels

1B 2B
1C
1D
1E
1F

Steering
 Brakes and Brake Controls
 Fuel, Exhaust and Emission Systems
 Cooling, Heating and Air Conditioning
 Electrical, Washers/Wipers, Instruments

1G
1H
1I - J
1K
1L - M

Chassis, Subframes, Bodyshell, Fittings
 Fascia, Trim, Seats and Fixings
 Miscellaneous
 Numerical Index

2C
2D
2E
2F

2G16

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
WKC 3924	CANTRAIL ASSY RH	2005	WKC 4792 RH	DOOR TRIMPAD RH	2006
WKC 3935 PA	HOOD STOWAGE COVER	2011	WKC 4823 RG	FRONT SEAT ASSY LH	2012
WKC 3937 PA	COVER HEADER RAIL	2012	WKC 4823 RH	FRONT SEAT ASSY LH	2012
WKC 3943 AA	REAR QUARTER TRIMBOARD LH	2005	WKC 4824 RG	FRONT SEAT ASSY RH	2012
WKC 3944 AA	REAR QUARTER TRIMBOARD RH	2005	WKC 4824 RH	FRONT SEAT ASSY RH	2012
WKC 3949	FINISHER DRIP MOULDING CHANNEL	2012	WKC 4833 RG	FRONT SEAT ASSY LH	2012
WKC 3950	FINISHER DRIP MOULDING CHANNEL	2012	WKC 4831 RH	FRONT SEAT ASSY LH	2012
WKC 4018	HANDBRAKE HEATSHIELD	1H07	WKC 4832 RG	FRONT SEAT ASSY RH	2012
WKC 4077	FRONT PANEL	2003	WKC 4832 RH	FRONT SEAT ASSY RH	2012
WKC 4101	DOOR SEAL LH	2005	WKC 4843 AM	SUN VISOR LH	2008
WKC 4102	DOOR SEAL RH	2005	WKC 4843 JJ	SUN VISOR LH	2008
WKC 4252	FENDER VALANCE LH	2004	WKC 4854 AM	SUN VISOR RH	2008
WKC 4253	FENDER VALANCE RH	2004	WKC 4854 JJ	SUN VISOR RH	2008
WKC 4255	REAR DECK ASSY	2012	WKC 4863 AM	SUN VISOR LH	2008
WKC 4267	FRONT WING LH	2003	WKC 4863 JJ	SUN VISOR LH	2008
WKC 4268	FRONT WING RH	2003	WKC 4870 AM	SUN VISOR RH	2008
WKC 4389	BODYSHELL-CONVERTIBLE	2002	WKC 4870 JJ	SUN VISOR RH	2008
WKC 4436	BODYSHELL-SUNROOF	2002	WKC 4922 AM	COVER HEADER RAIL	2012
WKC 4439	BODYSHELL	2002	WKC 4922 JJ	COVER HEADER RAIL	2012
WKC 4601 AD	FLOOR CARPET	2015	WKC 4951 AM	BACKLIGHT COVER	2007
WKC 4601 JJ	FLOOR CARPET	2015	WKC 4951 JJ	BACKLIGHT COVER	2007
WKC 4604 AD	SILL CARPET RH	2015	WKC 4955 PA	SUNSHINE ROOF	2009
WKC 4604 JJ	SILL CARPET RH	2015	WKC 4961 PA	TRIM CARPET-BOOT FLOOR	2015
WKC 4605 AD	SILL CARPET LH	2015	WKC 5050	FENDER VALANCE LH	2004
WKC 4605 JJ	SILL CARPET LH	2015	WKC 5051	FENDER VALANCE RH	2004
WKC 4611 AM	REAR QUARTER TRIMBOARD LH	2005	WKC 5059	FRONT LONGITUDINAL ASSY LH	2004
WKC 4611 JJ	REAR QUARTER TRIMBOARD LH	2005	WKC 5060	FRONT LONGITUDINAL ASSY RH	2004
WKC 4612 AM	REAR QUARTER TRIMBOARD RH	2005	WKC 5061	FRONT BUMPER ASSY	2014
WKC 4612 JJ	REAR QUARTER TRIMBOARD RH	2005	WKC 5112	LOWER FINISHER	2013
WKC 4614 AM	REAR PARCEL SHELF	2007	WKC 5164 LG	FACIA BASE MOULDING	2012
WKC 4614 JJ	REAR PARCEL SHELF	2007	WKC 5160 LG	COVER-E.L.C.U.	1H04
WKC 4624 AM	BULKHEAD TRIP PAD	2008	WKC 5224 RE	DOOR TRIMPAD LH	2006
WKC 4624 JJ	BULKHEAD TRIP PAD	2008	WKC 5224 RH	DOOR TRIMPAD LH	2006
WKC 4749	REAR SIDEMEMBER LH	2012	WKC 5225 RG	DOOR TRIMPAD RH	2006
WKC 4744	REAR SIDEMEMBER RH	2012	WKC 5225 RH	DOOR TRIMPAD RH	2006
WKC 4758	FRONT QTR GLASS ASSY LH	2008	WKC 5228 AM	DOOR TRIMPAD LH	2006
WKC 4759	FRONT QTR GLASS ASSY RH	2008	WKC 5228 JJ	DOOR TRIMPAD RH	2006
WKC 4782	WINDSCREEN	2013	WKC 5229 AM	DOOR TRIMPAD LH	2006
WKC 4795 RG	DOOR TRIMPAD LH	2006	WKC 5229 JJ	DOOR TRIMPAD RH	2006
WKC 4795 RH	DOOR TRIMPAD LH	2006	WKC 5282	DOOR ASSY LH	2007
WKC 4796 RG	DOOR TRIMPAD RH	2006	WKC 5283	DOOR ASSY RH	2007
WKC 4796 RH	DOOR TRIMPAD RH	2006	WKC 5286	DOOR ASSY LH	2007
WKC 4797 RG	DOOR TRIMPAD LH	2006	WKC 5287	DOOR ASSY RH	2007
WKC 4797 RH	DOOR TRIMPAD LH	2006	WKC 5301 AM	HOOD STOWAGE COVER	2011
WKC 4799 RG	DOOR TRIMPAD RH	2006	WKC 5301 JJ	HOOD STOWAGE COVER	2011

2G17

2617

GROUP INDEX

Introduction	1B-2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L-M

Chassis, Subframes, Bodyshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2G17

PART NUMBER	DESCRIPTION	REF. NO.
WL 204	WASHER	2D15
WL 205	WASHER	2C09
WL 205	WASHER	2D13
WL 205	WASHER	2D16
WL 217	WASHER	1E13
WL 207	WASHER	1G02
WL 207	WASHER	2C12
WL 104001	WASHER	1L14
WL 104001	WASHER	1M07
WL 104001	WASHER	2D04
WL 105001	WASHER	1I12
WL 105001	WASHER	1I15
WL 105001	WASHER	1J05
WL 105001	WASHER	1J06
WL 105001	WASHER	1K03
WL 105001	WASHER	1L08
WL 105001	WASHER	1L09
WL 105001	WASHER	1L14
WL 105001	WASHER	2C03
WL 105001	WASHER	2C06
WL 105001	WASHER	2C15
WL 106001	WASHER	1E04
WL 106001	WASHER	1E05
WL 106001	WASHER	1E06
WL 106001	WASHER	1F02
WL 106001	WASHER	1G08
WL 106001	WASHER	1H04
WL 106001	WASHER	1I06
WL 106001	WASHER	1I07
WL 106001	WASHER	1I09
WL 106001	WASHER	1I11
WL 106001	WASHER	1I13
WL 106001	WASHER	1I14
WL 106001	WASHER	1I15
WL 106001	WASHER	1J05
WL 106001	WASHER	1J06
WL 106001	WASHER	1K02
WL 106001	WASHER	1K03
WL 106001	WASHER	1K05
WL 106001	WASHER	1K06
WL 106001	WASHER	1K08
WL 106001	WASHER	1L09
WL 106001	WASHER	1L14
WL 106001	WASHER	1L15
WL 106001	WASHER	1L17

2618

PART NUMBER	DESCRIPTION	REF. NO.
WL 106001	WASHER	1M06
WL 106001	WASHER	1M07
WL 106001	WASHER	2C03
WL 106001	WASHER	2C05
WL 106001	WASHER	2C08
WL 106001	WASHER	2C10
WL 106001	WASHER	2C12
WL 106001	WASHER	2C16
WL 106007	WASHER	1I04
WL 106061	WASHER	1D02
WL 106121	WASHER	1I10
WL 106201	WASHER	1M07
WL 108014	WASHER	2D10
WL 108051	WASHER	1E04
WL 108051	WASHER	1E03
WL 110001	WASHER	1E02
WL 110001	WASHER	1F04
WL 110001	WASHER	1G03
WL 110001	WASHER	1I07
WL 110001	WASHER	2C14
WL 112001	WASHER	1D03
WL 112001	WASHER	1E15
WL 112001	WASHER	1F02
WL 112001	WASHER	1M02
WL 600071	WASHER LOCK	1C11
WL 700101	WASHER	1I12
WL 700101	WASHER	1I13
WM 57	WASHER	1I14
WM 57	WASHER	1I15
WM 57	WASHER	1I16
WM 57	WASHER	1K05
WM 57	WASHER	1K06
WM 57	WASHER	2C03
WM 57	WASHER	2C08
WM 57	WASHER	2C12
WM 58	WASHER	2C04
WM 83	WASHER	1F04
WM 91	WASHER	2C16
WM 803	WASHER	1F05
WM 809	WASHER	2D12
WM 600041	WASHER	1E05
WM 600041	WASHER	1I09
WM 600041	WASHER	1I10
WM 600041	WASHER	1J03
WM 600041	WASHER	1J04

2612

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I-J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers/Wipers, Instruments **1L-M**

Chassis, Subframes, Bodyshell, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2G18

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aeration Kühlung, Heizung, Luftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodyshell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2H01

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
WM 600041	WASHER	1C02	WM 308	WASHER	1H05
WM 600051	WASHER SPRING	1C02	XKC 17	CLOSING PANEL RH RADIATOR SIDE	2C04
WM 600051	WASHER SPRING	1C08	XKC 25	DASH TOP PANEL ASSY	2C05
WM 600051	WASHER LOCK	1C02	XKC 33	LOWER HINGE LH	2C05
WM 600051	WASHER	1108	XKC 34	LOWER HINGE RH	2C05
WM 600061	WASHER	1E07	XKC 35	GUTTER CHANNEL LH	2C11
WM 600061	WASHER	1J03	XKC 36	GUTTER CHANNEL RH	2C11
WM 600071	WASHER	1K04	XKC 63	WINDSCREEN TRIM HEADER RAIL	2C06
WM 702001	WASHER SPRING	1G08	XKC 112	OUTER SILL PANEL LH	2C10
WM 702001	WASHER	1104	XKC 113	OUTER SILL PANEL RH	2C10
WM 702001	WASHER	1109	XKC 123	GLASS RUN CHANNEL LH	2C08
WM 702001	WASHER	1J04	XKC 124	GLASS RUN CHANNEL RH	2C08
WM 702001	WASHER	1C02	XKC 141	TRUNK LID ASSEMBLY	2C12
WN 105001	WASHER	1L16	XKC 143	FILLER PANEL LH	2C12
WP 5	WASHER	1104	XKC 144	FILLER PANEL RH	2C12
WP 5	WASHER	1K06	XKC 147	REAR UPPER PANEL	2C12
WP 5	WASHER	1K08	XKC 148	CLOSING PANEL LH	2C03
WP 7	WASHER	2C12	XKC 149	CLOSING PANEL RH	2C03
WP 8	WASHER	1D04	XKC 163	WASHER BOTTLE MOUNTING BRACKET LHS	2C04
WP 8	WASHER	1H04	XKC 165	INNER SILL ASSEMBLY LH	2C10
WP 8	WASHER	2D03	XKC 167	INNER SILL ASSEMBLY RH	2C10
WP 11	WASHER	1F02	XKC 190	TONNEAU SIDE PANEL LH	2C11
WP 14	WASHER	1G02	XKC 191	TONNEAU SIDE PANEL RH	2C11
WP 17	WASHER	1K03	XKC 192	WHEELARCH ANGLE LH	2C11
WP 26	WASHER	2D04	XKC 193	WHEELARCH ANGLE RH	2C11
WP 28	WASHER	2D09	XKC 195	BATTERY TRAY SUPPORT LHS	2C04
WP 29	WASHER	1L16	XKC 217	SEAT SLIDE LH	2D12
WP 31	WASHER	1115	XKC 218	SEAT SLIDE RH	2D12
WP 41	WASHER	1G02	XKC 241 LG	CUBBY BOX UPPER ROLL	2D03
WP 65	WASHER	1M05	XKC 241 PA	CUBBY BOX UPPER ROLL MOULDING (HARD)	2D03
WP 104	WASHER	1K06	XKC 281	CENTRE SUPPORT ASSY	1K06
WP 104	WASHER	1K08	XKC 288	LOWER DEMISTER DUCT LH	1K05
WP 120	WASHER	1L09	XKC 322	INNER DISC LATCH LH	2C09
WP 120	WASHER	2C05	XKC 323	INNER DISC LATCH RH	2C09
WP 120	WASHER	2C14	XKC 324	TRUNK LID LOCK	2C12
WP 120	WASHER	2C16	XKC 325	WINDOW REGULATOR LH	2C08
WP 127	WASHER	1M07	XKC 326	WINDOW REGULATOR RH	2C08
WP 129	WASHER	1E15	XKC 327	OUTER DISC LATCH LH	2C09
WP 129	WASHER	1F04	XKC 328	OUTER DISC LATCH RH	2C09
WP 132	WASHER	1F03	XKC 331 PA	TREAD PLATE MOULDING	2C15
WP 163	WASHER	1H07	XKC 541 LG	CONSOLE INSERT MOULDING	2D04
WP 167	WASHER	1M07	XKC 541 PA	CONSOLE INSERT MOULDING	2D04
WP 181	WASHER	2D12	XKC 582	SEAT BELT BRACKET LH	2C11
WP 8005	WASHER	1M05	XKC 583	SEAT BELT BRACKET RH	2C11
WP 8016	WASHER	1F02	XKC 593	UPPER NACELLE LHS	1G06

2H02

2H02

GROUP INDEX

Introduction	1B 2B	Steering	1G	Chassis, Subframes, Bodyshell, Fittings	2C
Engine	1C	Brakes and Brake Controls	1H	Fascia, Trim, Seats and Fixings	2D
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J	Miscellaneous	2E
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K	Numerical Index	2F
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L-M		



PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
XKC 594	LOWER NACELLE LHS	1G06	XKC 1489	HC FRONT CARPET LH-EMERALD	2D14
XKC 768	LOWER DEMISTER DUCT LH	1K06	XKC 1557	DOOR WATER CURTAIN	2D06
XKC 770	REMOTE CONTROL HANDLE	2C09	XKC 1558	TRIMBOARD-SPARE WHEEL COVER	2D15
XKC 781	AA BULKHEAD TRIMPAD	2D07	XKC 1564	AA SEAT SQUAB COVER - BEIGE	2D13
XKC 791	CENTRE SUPPORT ASSY	1K08	XKC 1566	AA CUSHION COVER - BEIGE	2D13
XKC 795	DOOR HANDLE LH	2C09	XKC 2023	B POST LH	2C11
XKC 796	DOOR HANDLE RH	2C09	XKC 2024	B POST RH	2C11
XKC 981	PA MAP BOX HEATER CONSOLE	2D02	XKC 2198	PLENUM PANEL ASSY	2C05
XKC 1052	DEFLECTOR MouldING	1K05	XKC 2211	BATTERY BOX	1K07
XKC 1086	DEFLECTOR MouldING	1K06	XKC 2220	FRONT CHANNEL	2D10
XKC 1093	PA MARKER LAMP COVER	2D15	XKC 2223	REAR CHANNEL	2D10
XKC 1123	LOWER DEMISTER DUCT RH	1K06	XKC 2242	BONNET	2C03
XKC 1124	LOWER DEMISTER DUCT RH	1K05	XKC 2419	LG GRILLE MouldING	2D02
XKC 1201	AM ARMREST LID ASSY	2D04	XKC 2419	PA GRILLE MouldING	2D02
XKC 1201	JJ ARMREST LID ASSY	2D04	XKC 2475	PA TRIM CARPET-BOOT FLOOR	2D15
XKC 1201	PA ARMREST LID ASSY	2D04	XKC 2645	DEFLECTOR BLADE LH	2D10
XKC 1221	AM REAR CONSOLE CENTRE ARMREST	2D04	XKC 2646	DEFLECTOR BLADE RH	2D10
XKC 1221	JJ REAR CONSOLE CENTRE ARMREST	2D04	XKC 2647	REAR LAMP COVER LH	2D15
XKC 1221	PA REAR CONSOLE CENTRE ARMREST	2D04	XKC 2648	REAR LAMP COVER RH	2D15
XKC 1231	AM ARM REST LH	2D06	XKC 2695	AD HOOD STOWAGE BOARD LH	2D11
XKC 1231	JJ ARM REST LH	2D06	XKC 2695	JJ HOOD STOWAGE BOARD LH	2D11
XKC 1231	AA ARM REST LH BEIGE	2D06	XKC 2695	PA HOOD STOWAGE BOARD LH	2D11
XKC 1231	PA ARM REST LH BLACK	2D06	XKC 2696	AD HOOD STOWAGE BOARD RH	2D11
XKC 1232	AM ARM REST RH	2D06	XKC 2696	JJ HOOD STOWAGE BOARD RH	2D11
XKC 1232	JJ ARM REST RH	2D06	XKC 2696	PA HOOD STOWAGE BOARD RH	2D11
XKC 1232	AA ARM REST RH BEIGE	2D06	XKC 2698	AD HOOD STOWAGE BOARD-REAR	2D11
XKC 1232	PA ARM REST RH BLACK	2D06	XKC 2698	JJ HOOD STOWAGE BOARD-REAR	2D11
XKC 1251	LG LOWER MouldING	2D04	XKC 2698	PA HOOD STOWAGE BOARD-REAR	2D11
XKC 1251	PA LOWER MouldING	2D04	XKC 2701	NC SUN VISOR ASSY RH	2D08
XKC 1272	LG FRONT MouldING	2D04	XKC 2701	PA SUN VISOR RH	2D08
XKC 1272	PA FRONT MouldING LHS	2D04	XKC 2705	NC SUN VISOR ASSY LH	2D08
XKC 1365	DRIVERS FOOTREST	2C10	XKC 2705	PA SUN VISOR LH	2D08
XKC 1464	CC REAR CARPET LH-TARTAN RED	2D14	XKC 2717	SEAT BELT GUIDE LH	2D14
XKC 1464	HC REAR CARPET LH-EMERALD	2D14	XKC 2718	SEAT BELT GUIDE RH	2D14
XKC 1465	CC REAR CARPET RH-TARTAN RED	2D14	XKC 2742	AA DOOR TRIMPAD LH	2D06
XKC 1465	HC REAR CARPET RH-EMERALD	2D14	XKC 2742	RA DOOR TRIMPAD LH	2D06
XKC 1466	CC SILL CARPET LH-TARTAN RED	2D14	XKC 2742	RB DOOR TRIMPAD LH	2D06
XKC 1466	HC SILL CARPET LH-EMERALD	2D14	XKC 2743	RB DOOR TRIMPAD RH	2D06
XKC 1467	CC SILL CARPET RH-TARTAN RED	2D14	XKC 2743	AA DOOR TRIMPAD RH	2D06
XKC 1467	HC SILL CARPET RH-EMERALD	2D14	XKC 2743	RA DOOR TRIMPAD RH	2D06
XKC 1479	CC GEARBOX CARPET-TARTAN RED	2D14	XKC 2744	AD SILL CARPET LH-CHESTNUT	2D14
XKC 1479	HC GEARBOX CARPET-EMERALD	2D14	XKC 2745	AD SILL CARPET RH-CHESTNUT	2D14
XKC 1488	CC FRONT CARPET RH-TARTAN RED	2D14	XKC 2793	D RIP CHANNEL LH	2C06
XKC 1488	HC FRONT CARPET RH-EMERALD	2D14	XKC 2794	D RIP CHANNEL RH	2C06
XKC 1489	CC FRONT CARPET LH-TARTAN RED	2D14	XKC 2813	RA SEAT SQUAB COVER	2D13

2H03

2H03

GROUP INDEX

Introduction	1B-2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I-J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L-M

Chassis, Subframes, Bodyshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2H03

PART NUMBER	DESCRIPTION	REF. NO.
XKC 2813 RB	SEAT SQUAB COVER	2D13
XKC 2814 RA	SEAT CUSHION COVER	2D13
XKC 2814 RB	SEAT CUSHION COVER	2D13
XKC 2819	WEATHERSTRIP FRONT	2C08
XKC 2820	WEATHERSTRIP FRONT	2C08
XKC 2860	EDGE FINISHER LH	2D12
XKC 2861	EDGE FINISHER RH	2D12
XKC 2875	UPPERFRAME-FRONT	2C08
XKC 2876	UPPER FRAME-FRONT	2C08
XKC 2877	HEADER RAIL ASSY	2D11
XKC 2894	REAR DECK ASSY	2C12
XKC 2895	A POST UPPER LH	2C05
XKC 2896	A POST UPPER RH	2C05
XKC 2902 LG	LENS COVER-CONSOLE	1K06
XKC 2902 LG	LENS COVER-CONSOLE	1K08
XKC 2902 PA	LENS COVER-CONSOLE	1K06
XKC 2902 PA	LENS COVER-CONSOLE	1K05
XKC 2903	CANTRAIL ASSY LH	2C06
XKC 2904	CANTRAIL ASSY RH	2C06
XKC 2931	INSULATION PAD	2D17
XKC 2969	B POST CLOSING PANEL LH	2C11
XKC 2970	B POST CLOSING PANEL RH	2C11
XKC 2971	FINISHER-DOOR WAIST-REAR LH	2D12
XKC 2972	FINISHER-DOOR WAIST-REAR RH	2D12
XKC 2975	STRAP-UPPER TO LOWER PANEL	2C03
XKC 3010	RUBBER EXTRUSION-FRONT	2C08
XKC 3011	RUBBER EXTRUSION-REAR	2C08
XKC 3020	CLOSING PANEL	2D16
XKC 3021	GASKET	2D16
XKC 3037	ESCUTCHEON	1L14
XKC 3037	ESCUTCHEON	1L15
XKC 3069	ESCUTCHEON	1L14
XKC 3069	ESCUTCHEON	1L15
XKC 3207	QTR GLASS WEATHERSEAL LH	2C08
XKC 3208	QTR GLASS WEATHERSEAL RH	2C08
XKC 3209 PA	INNER QTR PANEL COVER LH	2D08
XKC 3210 PA	INNER QTR PANEL COVER RH	2D08
XKC 3211 AD	WHEELARCH COVER CARPET LH	2D08
XKC 3211 JJ	WHEELARCH COVER CARPET LH	2D08
XKC 3211 PA	WHEELARCH COVER CARPET LH	2D08
XKC 3212 AD	WHEELARCH COVER CARPET RH	2D08
XKC 3212 JJ	WHEELARCH COVER CARPET RH	2D08
XKC 3212 PA	WHEELARCH COVER CARPET RH	2D08
XKC 3258 CC	SILL CARPET RH-TARTAN RED	2D14
XKC 3258 HC	SILL CARPET RH-EMERALD	2D14

2H04

PART NUMBER	DESCRIPTION	REF. NO.
XKC 3259 CC	SILL CARPET LH-TARTAN RED	2D14
XKC 3259 HC	SILL CARPET LH-EMERALD	2D14
XKC 3335	BATTERY MOUNTING TRAY	1M07
XKC 3348	BATTERY CLAMP	1M77
XKC 3419	TRUNK LID HINGE ASSY RH	2C12
XKC 3420	TRUNK LID HINGE ASSY LH	2C12
XKC 3422 PA	MAT-LUGGAGE COMPARTMENT	2D16
XKC 3425	REAR DECK ASSY	2C12
XKC 3471	GAS STRUT	2C12
XKC 3517	SEAT BELT ASSY	2D14
XKC 3580 AD	SILL CARPET RH	2D15
XKC 3580 JJ	SILL CARPET RH	2D15
XKC 3581 AD	SILL CARPET LH	2D15
XKC 3581 JJ	SILL CARPET LH	2D15
XKC 3588 AM	BULKHEAD TRIMPAD	2D07
XKC 3588 JJ	BULKHEAD TRIMPAD	2D07
XKC 3591 AM	A POST TRIMBOARD LH	2D05
XKC 3591 JJ	A POST TRIMBOARD LH	2D05
XKC 3593 AM	A POST TRIMBOARD LH	2D05
XKC 3593 JJ	A POST TRIMBOARD LH	2D05
XKC 3595 AM	A POST TRIMBOARD RH	2D05
XKC 3595 JJ	A POST TRIMBOARD RH	2D05
XKC 3597 AM	A POST TRIMBOARD RH	2D05
XKC 3597 JJ	A POST TRIMBOARD RH	2D05
XKC 3604	PLENUM PANEL	2C05
XKC 3611 AM	CONSOLE KNEE PAD LH	2D02
XKC 3611 JJ	CONSOLE KNEE PAD LH	2D02
XKC 3612 AM	CONSOLE KNEE PAD RH	2D02
XKC 3612 JJ	CONSOLE KNEE PAD RH	2D02
XKC 3630	HEELBOARD PANEL ASSY	2C12
XKC 3668 AM	GEARLEVER GAITOR AND	2D04
XKC 3668 JJ	GEARLEVER GAITOR AND	2D04
XKC 3672	QUARTER GLASS ASSY LH	2C08
XKC 3673	QUARTER GLASS ASSY RH	2C08
XKC 3676	DOOR GLASS ASSY LH	2C08
XKC 3677	DOOR GLASS ASSY RH	2C08
XKC 3681	QUARTER GLASS ASSY LH	2C08
XKC 3682	QUARTER GLASS ASSY RH	2C08
XKC 369 AM	HANDBRAKE GAUNTLET	2D15
XKC 3696 JJ	HANDBRAKE GAUNTLET	2D15
XKC 3724	RADIATOR BLANKING BOARD RH	1K02
XKC 3725	RADIATOR BLANKING BOARD LH	1K02
XKC 3728 RG	SEAT CUSHION COVER	2D13
XKC 3728 RH	SEAT CUSHION COVER	2D13
XKC 3730 RG	SEAT SQUAB COVER	2D13

2H04

GROUP INDEX

Introduction	1B 2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - M

Chassis, Subframes, Bodvshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2H04

PART NUMBER	DESCRIPTION	REF. NO.
XKC 3730 RH	SEAT SQUAB COVER	2D13
XKC 3734 AM	SEAT CUSHION COVER	2D13
XKC 3734 JJ	SEAT CUSHION COVER	2D13
XKC 3735 AM	SEAT SQUAB COVER	2D13
XKC 3735 JJ	SEAT SQUAB COVER	2D13
XKC 3736 PA	MAT-LUGGAGE COMPARTMENT	2D16
XKC 3763	INNER QTR PANEL COVER LH	2D08
XKC 3763	INNER QTR PANEL COVER LH	2D08
XKC 3764	INNER QTR PANEL COVER RH	2D08
XKC 3764	INNER QTR PANEL COVER RH	2D08
XKC 3769	WASHER BOTTLE MOUNTING	2C04
XKC 3778	SUPPORT RAIL LHS(DRIVERS)	1G06
XKC 3791	FLEXIBLE MOUNTING LH	2C14
XKC 3792	FLEXIBLE MOUNTING RH	2C14
XKC 3806	ROOF INSULATION PAD	2D09
XKC 3822	BONNET	2C03
XKC 3847	SEAL-A POST UPPER LH	2D12
XKC 3848	SEAL-A POST UPPER RH	2D12
XKC 3851	TRUNK LID LOCK	2C12
XKC 3854	TRUNK LID ASSEMBLY	2C12
XKC 3858	REMOTE CONTRL HANDLE	2C09
XKC 3893	GAS STRUT	2C12
XKC 3902	FRONTAL BADGE	2C16
XKC 3913 PA	REAR CONSOLE CENTRE ARMREST	2D04
XKC 3924	BONNET RELEASE CABLE	2C04
YH 6405	SCREW	1E14
YH 6604	SCREW	1L15
YH 6604	SCREW	1L17
YH 8505	SCREW	1K06
YKC 31	JACK MOUNTING BRACKET	2C10
YKC 68	TRUNK LID WEATHERSTRIP	2C12
YKC 71	CLOSING PANEL LH	2C11
YKC 72	CLOSING PANEL RH	2C11
YKC 74	DOOR OUTER PANEL LH	2C07
YKC 75	DOOR OUTER PANEL RH	2C07
YKC 83	OUTER TUBE (SUPP. RAIL)	1G06
YKC 84	INNER TUBE (SUPP. RAIL)	1G06
YKC 90	DOOR GLASS RUBBER CHANNEL	2D06
YKC 102	OUTER WAIST SEAL LH	2C07
YKC 103	OUTER WAIST SEAL RH	2C07
YKC 132	SUPPORT RAIL LHS PASSENGERS	1G06
YKC 150	BONNET LOCK	2C04
YKC 174	SILL MOULDING	2C15
YKC 191	ESCUTCHEON	2D08
YKC 191 PA	ESCUTCHEON	2D06

2H05

PART NUMBER	DESCRIPTION	REF. NO.
YKC 209	TURN BUTTON (TRUNK LOCK)	2C12
YKC 211 PA	HANDLE BEZEL	2D13
YKC 245	MOULDING-VENT TO HEATER TAKE OFF	2D03
YKC 253	UPPER ATTACHMENT BRACKET LH	2D02
YKC 254	UPPER ATTACHMENT BRACKET RH	2D02
YKC 320	SEAL-PLENUM TO DASH	2C05
YKC 401 PA	FACIA END VENT	2D03
YKC 441 PA	CENTRE FACE LEVEL VENT	2D03
YKC 504	TRUNK LOCK STRIKER	2C12
YKC 530	CUBBY BOX HINGE LH	2D03
YKC 531	CUBBY BOX HINGE RH	2D03
YKC 566	A POST VENTILATOR	2D05
YKC 573	UPPER DEMISTER DUCT LH	1K05
YKC 573	UPPER DEMISTER DUCT LH	1K06
YKC 581 AA	HEADREST-BEIGE	2D12
YKC 682	HEADLAMP MOUNTING PANEL LH	1L08
YKC 683	HEADLAMP MOUNTING PANEL RH	1L08
YKC 730	BONNET RELEASE CABLE	2C04
YKC 874	FRONT BUMPER MOULDING	2C14
YKC 917	LISTING RAIL	2D09
YKC 931	COURTESY LIGHT SWITCH	1L16
YKC 957	EXHAUST MOUNTING BRACKET LH	1117
YKC 961	SCREEN WASHER BOTTLE ASSY	1L12
YKC 970	ASHTRAY	2D06
YKC 985	TIE-DOWN BRACKET LH	2C15
YKC 986	TIE-DOWN BRACKET RH	2C15
YKC 1115 PA	FACIA TOP PAD LH	2D02
YKC 1116 PA	FACIA TOP PAD RH	2D02
YKC 1154	UPPER DEMISTER DUCT RH	1K05
YKC 1154	UPPER DEMISTER DUCT RH	1K06
YKC 1264	SCREW	1J02
YKC 1342	PARKING DEVICE-SEAT BELTS	2D14
YKC 1347	MECHANISM MAINSPRING	1L09
YKC 1432	AIR INTAKE MULDING LH	1J02
YKC 1433	AIR INTAKE MULDING RH	1J02
YKC 1551	CLOSING PANEL LH	2C04
YKC 1552	CLOSING PANEL RH	2C04
YKC 1553	FUSIBLE PAD-TRUNK FLOOR	2D16
YKC 1554	FUSIBLE PAD-FRONT FOOTWELL LH	2C16
YKC 1555	FUSIBLE PAD-REAR FOOTWELL RH	2D16
YKC 1556	FUSIBLE PAD-REAR FOOTWELL LH	2D16
YKC 1557	FUSIBLE PAD-REAR FOOTWELL RH	2D16
YKC 1609	INSULATION PAD	2D16
YKC 1610	CUBBY BOX LOCK ASSEMBLY	2D03
YKC 1675	DEFLECTOR EXTENSION LH	1K06

2H05

GROUP INDEX

Introduction **1B 2B**
 Engine **1C**
 Flywheel and Clutch **1D**
 Gearbox and Propshaft **1E**
 Axles, Suspension, Drive Shafts, Wheels **1F**

Steering **1G**
 Brakes and Brake Controls **1H**
 Fuel, Exhaust and Emission Systems **1I - J**
 Cooling, Heating and Air Conditioning **1K**
 Electrical, Washers/Wipers, Instruments **1L - M**

Chassis, Subframes, Bodyshe'll, Fittings **2C**
 Fascia, Trim, Seats and Fixings **2D**
 Miscellaneous **2E**
 Numerical Index **2F**

2H05

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
YKC 1750	STEADY STAY	1G06	YKC 3290	CLOSING PANEL LH RADIATOR SIDE	2C04
YKC 1757 AA	A POST TRIMBOARD LH	2D05	YKC 3282	PROTECTION FLUG LH	2C08
YKC 1759 AA	A POST TRIMBOARD LHS BEIGE	2D05	YKC 3283	PROTECTION PLUG RH	2C08
YKC 1761 AA	A POST TRIMBOARD LHS BEIGE	2D05	YKC 3290	DOOR RESTRAINT ASSY	2C07
YKC 1763 AA	A POST TRIMBOARD LHS BEIGE	2D05	YKC 3301	ATTACHMENT BRACKET	2D11
YKC 1770	SEAL	1K03	YKC 3320	WINDSHIELD PANEL	2C06
YKC 1779	BASE PLINTH	2C13	YKC 3325	PLATE	2D02
YKC 1859 LG	HEATER CONSOLE	2D02	YKC 3330	FINISHER B POST TOP LH	2D12
YKC 1859 PA	HEATER CONSOLE	2D02	YKC 3331	FINISHER B POST TOP RH	2D12
YKC 1882 LG	HEATER CONSOLE A/C	2D02	YKC 3341	RETAINER-SEAL-HEADER RAIL LH	2D11
YKC 1882 PA	CENTRE CONSOLE A/C	2D02	YKC 3342	RETAINER-SEAL-HEADER RAIL RH	2D11
YKC 1887	PLENUM PANEL WEATHERSTRIP	2C05	YKC 3355	MOULDING BEZEL-FUEL FILLER	1I06
YKC 1890	WEATHERSTRIP CENTRE	2C03	YKC 3365	MOULDING BEZEL-FUEL FILLER	1I06
YKC 1891	WEATHERSTRIP LH	2C03	YKC 3376	FINISHER A POST TOP LH	2D12
YKC 1892	WEATHERSTRIP RH	2C03	YKC 3377	FINISHER A POST TOP RH	2D12
YKC 1895	GEAR LEVER GROMMET	1E06	YKC 3398	FUEL FILLER CAP	1I06
YKC 1896	MOUNTING BRACKET (AERIAL)	2C11	YKC 3505	STOP BRACKET LH	2D10
YKC 2119	EXHAUST MOUNTING BRACKET RH	1I17	YKC 3506	STOP BRACKET RH	2D10
YKC 2131	LID-BATTERY BOX	1M07	YKC 3561	CENTRE PIVOT ROD	2C14
YKC 2360	BATTERY BOX TRAY	1M07	YKC 3565 PA	CONSOLE KNEE PAD LH	2D02
YKC 2361	BATTERY MOUNTING TRAY	1M07	YKC 3566 PA	CONSOLE KNEE PAD RH	2D02
YKC 2374	FRONT SLIDE LH	2D09	YKC 3575	LOCATING PLATE LH	2D14
YKC 2375	FRONT SLIDE RH	2D09	YKC 3576	LOCATING PLATE RH	2D14
YKC 2380	COVER PLATE	2D09	YKC 3590	WINDSHIELD PANEL	2C06
YKC 2410	CLOSING PANEL-FRONT	2C05	YKC 3610	EDGE FINISHER-WINDSCREEN	2D12
YKC 2411	CLOSING PANEL-FRONT	2C05	YKC 3620	STOP BRACKET ASSY LH	2C08
YKC 2500	AERIAL	1M08	YKC 3621	STOP BRACKET ASSY RH	2C08
YKC 2501	BONNET SUPPORT STAY	2C03	YKC 3632	INSULATION PAD	2D17
YKC 2630	TRIM PAD LH-BOOT	2D15	YKC 3632	INSULATION PAD	2D16
YKC 2631	TRIM PAD LH-BOOT	2D15	YKC 3654	TRIMBOARD LH	2D16
YKC 2866	SNAP CAP	2C13	YKC 3656	TRIMBOARD RH	2D16
YKC 2940 1	BRACKET LH	2D08	YKC 3808	SIDE PANEL FH	2C12
YKC 2940 2	BRACKET RH	2D08	YKC 3823	INSULATION PAD	2D17
YKC 2953	BLANKING BOARD	1K02	YKC 3882	SUPPORT RAIL LHS (DRIVERS)	1G06
YKC 2954	BLANKING BOARD	1K02	YKC 4010	FOIL BADGE COBBY BOX LID	2D03
YKC 3155 PA	A POST TRIMBOARD LH	2D05	YKC 4029	GEAR LEVER GROMMET	1E06
YKC 3157	INTERMEDIATE SLIDE	2D09	YKC 4053	CONSOLE MOUNTING BRACKET	1K06
YKC 3157 PA	A POST TRIMBOARD LH	2D05	YKC 4053	CONSOLE MOUNTING BRACKET	1K06
YKC 3159 PA	A POST TRIMBOARD RH	2D05	YKC 4098	BRACKET	2C12
YKC 3161 PA	A POST TRIMBOARD RH	2D05	YKC 4195	LOCKING PLATE LH	2D11
YKC 3166 PA	HANDBRAKE CAUNTLET	2D14	YKC 4196	LOCKING PLATE RH	2D11
YKC 3169 PA	HEAD RESTRAINT	2D12	YKC 4199	DOOR GLASS ASSY LH	2C08
YKC 3178 PA	GEARLEVER GAITOR AND	2D04	YKC 4200	DOOR GLASS ASSY RH	2C08
YKC 3261	INSULATION PAD	2D16	YKC 4202	BACKLIGHT GLASS	2C13
YKC 3274	SEAT BELT ASSY	2D14	YKC 4246	BATTERY COVER STRAP	1M07

2H06

2H06

GROUP INDEX

Introduction	1B 2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers-Wipers, Instruments	1L - 2H

Chassis, Subframes, Bodyshell, Fittings 2C
 Fascia, Trim, Seats and Fixings 2D
 Miscellaneous 2E
 Numerical Index 2F

2106

PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.
YKC 4249 AM	HEAD RESTRAINT	2D12	ZKC 99	STAY-CUBBY BOX LID	2D03
YKC 4249 JJ	HEAD RESTRAINT	2D12	ZKC 110	SUPPORT BRACKET	1K06
YKC 4250 AM	HEAD RESTRAINT	2D12	ZKC 111	LOWER FACIA SUPPORT BRACKET	2D02
YKC 4250 JJ	HEAD RESTRAINT	2D12	ZKC 141	SEAT SLIDE BAR	2D12
YKC 4270	TRANSFER-BLACK	2C16	ZKC 182	COVER PLATE	2D15
YKC 4271	TRANSFER-ALUMINIUM	2C16	ZKC 221	WASHER-SPECIAL	2D12
YKC 4272	TRANSFER-BUCKSKIN	2C16	ZKC 227	FIXING PLATE	2C14
YKC 4373	BLANKING PLUG	2D10	ZKC 227	FIXING PLATE	2C15
YKC 4379	DISTANCE PIECE	2C14	ZKC 231	SLEEVE	1K06
YKC 4466	BONNET LOCK	2C04	ZKC 231	SLEEVE	1K06
YKC 4470	WINDSHIELD PANEL	2C06	ZKE 239	TAPPED PLATE	2D03
YKC 4471	WINDSHIELD PANEL	2C06	ZKC 314	UPPER FLAP (AIR EXTRACTOR)	2C16
YKC 4493	SCREW	2D03	ZKC 315	LOWER FLAP (AIR EXTRACTOR)	2C16
YKC 4494	DOOR BUFFER RH	2C07	ZKC 324	STRIKER (SNAP FIT TO HINGE)	2D04
YKC 4495	DOOR BUFFER LH	2C07	ZKC 368	FINISHER SPACER	2C13
YKC 4507	SILL LINK	2C09	ZKC 369	STRIKER SEAL	2C09
YKC 4530	RETAINING CLIP	2C12	ZKC 385	STRIKER COVER PLATE	2C09
YKC 4531	TURN BUTTON (TRUNK LOCK)	2C12	ZKC 397	HANDLE LINK LH	2C09
YKC 4545	HEATER CONSOLE	2D02	ZKC 398	HANDLE LINK RH	2C09
YKC 4617 LG	HEATER CONSOLE AC	2D02	ZKC 399	LOCK LINK LH	2C09
YKC 4684	DEFLECTOR EXTENSION	1K06	ZKC 400	LOCK LINK RH	2C09
YKC 4690 PA	STUD	2D12	ZKC 412	SPEAKER	1K06
YKC 4696	RADIATOR BLANKING BOARD	1K02	ZKC 417	SILL LINK LH	2C09
YN 2910	NUT	1F05	ZKC 418	SILL LINK RH	2C09
YS 3403	SCREW	2D15	ZKC 420	SEAL (FACIA TO WINDSCREEN)	2D02
YS 3403	SPIRE NUT	2D16	ZKC 430	FINISHER CAPPING	2C13
YT 5503	SCREW	1K08	ZKC 434	PLATE	2D05
YZ 3103	SCREW	2D13	ZKC 435	DOOR BUFFER	2C07
YZ 3304	SCREW	1L11	ZKC 440	CONSOLE SEAL	1K06
YZ 3304	SCREW	1L16	ZKC 440	CONSOLE SEAL	1K08
YZ 3403	SCREW	1K06	ZKC 441	RADIO SUPPORT PAD	1K06
YZ 3403	SCREW	1M05	ZKC 441	RADIO SUPPORT PAD	1K06
YZ 3404	SCREW	2C09	ZKC 446	SHOULDERED SCREW	2D02
YZ 3404	SCREW	2C13	ZKC 447	RETAINER (SUN VISOR)	2D08
YZ 3405	BOLT	1E06	ZKC 452	PLUG-VALANCE FENDER PASSENGER SIDE	2E02
YZ 3445	SCREW	2D02	ZKC 456	PLAIN WASHER	2D08
YZ 3485	SCREW	1M05	ZKC 457	LISTING RAIL CAP	2D09
YZ 3504	SCREW	1M06	ZKC 470	CATCH ASSEMBLY (LID)	2D04
YZ 3505	SCREW	2D14	ZKC 471	LOCK NUT	3D07
YZ 3508	SCREW	2D04	ZKC 477	WAVED WASHER	2D08
YZ 3514	SCREW	1M06	ZKC 478	STRIKER (CUBBY BOX LID)	2D03
YZ 5505	SCREW	2D09	ZKC 479	TAPPING PLATE-STRIKER TO FACIA	2D03
ZKC 2	PLATE WASHER	2C05	ZKC 510	SEALING WASHER	2C16
ZKC 19	TAPPED PLATE	2C03	ZKC 510	SEALING WASHER	1L10
ZKC 73	PLATE WASHER	2C03	ZKC 515	BOLT	2C16

2H07

2H07

GROUP INDEX

Introduction	1B 2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - 1S

Chassis, Subframes, Bodyshell, Fittings 2C
Fascia, Trim, Seats and Fixings 2D
Miscellaneous 2E
Numerical Index 2F

2H07

PART NUMBER	DESCRIPTION	REF. NO.
ZKC 2105	WHEELARCH COVER (REAR)	2C11
ZKC 2175	HINGE REINFORCEMENT	2C03
ZKC 2186	RETAINING RING	1E06
ZKC 2222	JACKNUT	2C03
ZKC 2226	JACKNUT	2C03
ZKC 2228	JACK NUT	1J05
ZKC 2236	MIRROR REINFORCEMENT	2C06
ZKC 2244	CLAMPING PLATE	1L09
ZKC 2245	MOUNTING BRACKET	1H06
ZKC 2261	BLANKING PLATE	1L11
ZKC 2267	BRACKET	2C12
ZKC 2275	ROOF SEAL	2D09
ZKC 2292	BATTERY BOX	1M07
ZKC 2530	TRIMBOARD LH	2D16
ZKC 2532	TRIMBOARD RH	2D16
ZKC 2562	SHIM-CUBBY BOX LID HINGE	2D03
ZKC 2571	SEAL	2C18
ZKC 2580	SHIM (BONNET HINGE)	2C03
ZKC 2592	PROJECTION Moulding LH	2C15
ZKC 2593	PROJECTION Moulding RH	2C15
ZKC 2595	GASKET-REAR PARKER LAMP	1L10
ZKC 2674	LIFTING SPRING LH	2D10
ZKC 2675	LIFTING SPRING	2D10
ZKC 2688	CAP TRIM	2D09
ZKC 2724	BEZEL	2C09
ZKC 2728	SILL BUTTON	2C09
ZKC 2734	GROMMET	1M07
ZKC 2785	ANCHOR BRACKET LH	2C04
ZKC 2786	ANCHOR BRACKET RH	2C04
ZKC 3099	WEATHERSEAL	2D11
ZKC 3176	BOUND INSULATION PAD	2D16
ZKC 3245	JACK STOWAGE PAD	2D13
ZKC 3296	INSULATION PAD	2D17
ZKC 3302	PLATE WASHER	2C05
ZKC 3415	BONNET BUFFER	2C03
ZKC 3464	HOOK-DOOR RESTRAINT	2C07
ZKC 3513	SEAL	2C13
ZKC 3521	PEG FIXING BUFFER	2C03
ZKC 3541	GASKET	1H06
ZKC 3548	BRACKET	2D08
ZKC 3652	LOCATION PLATE	2C14
ZKC 3668	BUSH-CENTRE PIVOT	2C14
ZKC 3671	FINISHER	2D10
ZKC 3684 NE	HEADLINING	2D09
ZKC 3685 NE	HEADLINING	2D09

2H09

PART NUMBER	DESCRIPTION	REF. NO.
ZKC 3702	BRIDGE	2C14
ZKC 3709	BOLT	2C14
ZKC 3726	BOLT	2C12
ZKC 3736	INSULATION PAD	2D17
ZKC 3748	LABEL	2C03
ZKC 3800	GASKET-DOOR RESTRAINT	2C07
ZKC 3946	SEAL	2C13
ZKC 3962	SCREW	1M04

2H09

GROUP INDEX

Introduction	1B 2B	Steering	1G
Engine	1C	Brakes and Brake Controls	1H
Flywheel and Clutch	1D	Fuel, Exhaust and Emission Systems	1I - J
Gearbox and Propshaft	1E	Cooling, Heating and Air Conditioning	1K
Axles, Suspension, Drive Shafts, Wheels	1F	Electrical, Washers/Wipers, Instruments	1L - 2H

Chassis, Subframes, Bodyshell, Fittings	2C
Fascia, Trim, Seats and Fixings	2D
Miscellaneous	2E
Numerical Index	2F

2H09

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aération Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodysell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2101

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aeration Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodyshell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2J01

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières illustrée Verzeichnis der Abbildungen.</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetsches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aération Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodysheff, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2K01

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refrondissement, Chauffage, Aération Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodyshell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2101

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aération Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodysht Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2M01

GROUP INDEX, TABLE DES SECTIONS, GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial Index Table des Matières Illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aération Kühlung, Heizung, Lüftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodyshell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index index Numérique Nummernverzeichnis</p>	<p>2F</p>

2N01

GROUP INDEX. TABLE DES SECTIONS. GRUPPENVERZEICHNIS.

<p>Group A Introduction Introduction Einführung</p>	<p>1B 02 2B 02</p>	<p>Group G Brakes and Brake Controls Freins Et Commandes Bremsen und Bedienungsorgane</p>	<p>1H</p>
<p>Group A Pictorial index Table des Matières illustrée Verzeichnis der Abbildungen</p>	<p>1B 08 2B 08</p>	<p>Group H Fuel, Exhaust, Emission Systems Systèmes d'alimentation en carburant, d'échappement et d'anti-pollution Kraftstoff-, Auspuff- und Abgasentgiftungsanlagen</p>	<p>1I - J</p>
<p>Group A Alphabetical Index Table alphabétique Alphabetisches Verzeichnis</p>	<p>1B 10 2B 10</p>	<p>Group J Cooling, Heating and Air Conditioning Refroidissement, Chauffage, Aération Kühlung, Heizung, Luftung</p>	<p>1K</p>
<p>Group B Engine Moteur Motor</p>	<p>1C</p>	<p>Group K Electrical, Washers-Wipers, Instruments Electricité, Essuie Glace, Instruments Elektrische, Scheibenwischer, Instrumente</p>	<p>1L - M</p>
<p>Group C Flywheel and Clutch Volant Et Embrayage Schwungrad und Kupplung</p>	<p>1D</p>	<p>Group L Chassis, Subframes, Bodysell, Fittings Chassis, Soubassement, Cabine Chassis Teile, Hilfsrahmen, Kabine</p>	<p>2C</p>
<p>Group D Gearbox and Propshaft Boîte de Vitesses et Cardan Getriebe und Antriebswelle</p>	<p>1E</p>	<p>Group M Fascia, Trim, Seats and Fixings Tableau de Bord, Garnitures Intérieure, Sièges Armaturenbrett, Polsterung und Sitz</p>	<p>2D</p>
<p>Group E Axles, Suspension, Drive Shafts, Wheels Axe, Suspension, Arbre de Commande, Roues Achse, Aufhängung, Antriebswelle, Rad</p>	<p>1F</p>	<p>Group N Miscellaneous Divers Vermischt</p>	<p>2E</p>
<p>Group F Steering Direction Lenkung</p>	<p>1G</p>	<p>Group P Numerical Index Index Numérique Nummernverzeichnis</p>	<p>2F</p>

2001