

TWS Lower Control Arm Brace Install

The TWS Lower Control Arm Braces are built to handle lots of horsepower and torque. These come partially painted, to allow you to weld the front half to the body frame rail.

Step 1 - Trim each side of the lower control ears

Measure the width of the TWS Lower Control Arm Braces ears and mark off the width (plus a little extra) and trim each side with a dremel tool



TWS MOTORS



144 W Britannia St. Building 25, Taunton MA 02780

1-508-880-5448 - contact@thewedgeshop.com <https://www.thewedgeshop.com>



Paint the bare metal areas before installing the braces

144 W Britannia St. Building 25, Taunton MA 02780

1 - 5 0 8 - 8 8 0 - 5 4 4 8 - contact@thewedgeshop.com <https://www.thewedgeshop.com>

Step 2 - Adjust lower frame rail if needed

Some cars may require you to flatten the lower seat support a bit. The oval holes may need to be hammered flat so that the braces sit flat. You may want to scrap off the undercoating as well.





144 W Britannia St. Building 25, Taunton MA 02780

1 - 5 0 8 - 8 8 0 - 5 4 4 8 - contact@thewedgeshop.com <https://www.thewedgeshop.com>

Step 3 - Mount the braces

Scuff up the welding area on the frame rail

Hold the the braces in place and weld to the frame

Install plastic end caps and finish painting the braces and underbody



TWS MOTORS



144 W Britannia St. Building 25, Taunton MA 02780

1 - 5 0 8 - 8 8 0 - 5 4 4 8 - contact@thewedgeshop.com <https://www.thewedgeshop.com>